



OWNER'S & INSTALLATION MANUAL AIR CONDITIONER

Please read this installation manual completely before installing the product.
Installation work must be performed in accordance with the national wiring standards by authorized personnel only.
Please retain this installation manual for future reference after reading it thoroughly..

WIRED REMOTE CONTROLLER



MFL69312302
Rev.31_010825

NEDERLANDS

ENGLISH

УКРАЇНЬСЬКА

FRANÇAIS

ITALIANO

DEUTSCH

ESPAÑOL

РУССКИЙ ЯЗЫК

POLSKI

PORTUGUÊS

中文

ČEŠTINA



www.lg.com

Copyright © 2016 - 2025 LG Electronics Inc. All Rights Reserved.

TIPS FOR SAVING ENERGY

Here are some tips that will help you minimize the power consumption when you use the air conditioner.

You can use your air conditioner more efficiently by referring to the instructions below:

- Do not cool excessively indoors. This may consume more electricity.
- Block sunlight with blinds or curtains while you are operating the air conditioner.
- Keep doors or windows closed tightly while you are operating the air conditioner.
- Adjust the direction of the air flow vertically or horizontally to circulate indoor air.
- Speed up the fan to cool or warm indoor air quickly, in a short period of time.
- Clean the air filter once every 2 weeks. Dust and impurities collected in the air filter may block the air flow or reduce the cooling / dehumidifying functions.

For your records

Staple your receipt to this page in case you need it to prove the date of purchase or for warranty purposes.

Write the model number and the serial number here:

Model number : _____

Serial number : _____

You can find them on a label on the side of each unit.

Dealer's name : _____

Date of purchase : _____

IMPORTANT SAFETY INSTRUCTIONS

READ ALL INSTRUCTIONS BEFORE USING THE APPLIANCE.

Always comply with the following precautions to avoid dangerous situations and ensure peak performance of your product

WARNING

This symbol indicates potentially hazardous situation which, if not avoided could result in death or serious injury.

CAUTION

This symbol indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.

- The instructions for class III appliances shall state that it must only be supplied at safety extra low voltage corresponding to the marking on the appliance.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

WARNING

Installation

- For electrical work, contact the dealer, seller, a qualified electrician, or an authorized service Center.
 - Do not disassemble or repair the product. There is risk of fire, electric shock, explosion, equipment malfunction, or injury.
- Request to the service center or installation specialty store when reinstalling the installed product.
 - There is risk of fire, electric shock, explosion, equipment malfunction, or injury.
- Do not disassemble, fix, and modify products randomly.
 - There is risk of fire, electric shock, explosion, equipment malfunction, or injury.
- The product shall be installed according to the national standards and local code.
- Apply totally enclosed noncombustible conduit in case of local building code requiring plenum.
- Use appropriate unit mounting procedures.
- Avoid direct sunlight.
- Avoid moist areas.

In-Use

- Do not place flammable objects close to the product.
 - There is risk of fire, electric shock, explosion, equipment malfunction or injury.
- Do not allow product to get wet.
 - There is risk of fire, electric shock, explosion, equipment malfunction or injury.
- Avoid dropping the product.
 - There is risk of fire, electric shock, explosion, equipment malfunction or injury.
- If product gets wet, contact your dealer or authorized service center.
 - There is risk of fire, electric shock, explosion, equipment malfunction, or injury. If the instructions are not followed, it may cause death or severe injury of the user.
- Do not use sharp or pointed objects on product.
 - There is risk of fire, electric shock, explosion, equipment malfunction or injury.
- Do not touch or pull the lead wire with wet hands.
 - There is risk of product breakdown or electric shock.

CAUTION

Installation

- If anyone other than a licensed professional installs, repairs, or alters LG Electronics air conditioning products, the warranty is voided.
 - All costs associated with repair are then the full responsibility of the owner.
- Do not install the unit in potentially explosive atmospheres.

In-use

- Do not clean using powerful detergents like solvent but use soft cloths.
 - There is risk of fire, electric shock, explosion, equipment malfunction or deformation.
- Do not press the screen using powerful pressure.
 - There is risk of product break-down or malfunction.

TABLE OF CONTENTS

2	TIPS FOR SAVING ENERGY
2	IMPORTANT SAFETY INSTRUCTIONS
9	DESCRIPTION
10	DESCRIPTION OF THE OPERATION
10	Main screen
10	Menu screen
11	Standby Screen
12	Setting screen
13	Popup screen
14	Monitoring / Air Quality Level / Sub function screens
18	Interface screen
18	Returning to the screen
19	OPERATION SETTING
19	On / Off
19	Operation mode
20	Cooling Operation
21	Heating Operation
22	Dry Operation
23	Fan Only Operation
24	AI / Auto operation
25	Dual setpoint auto operation
26	Power Cool Operation
26	Power Heat Operation
27	Ice Cool Power
28	OPERATION SETTING - VENTILATOR
28	Operation mode
29	TEMPERATURE SETTING
29	Controlling Desired Temperature
30	Check Room Temperature
31	WIND SETTING
31	Fan speed control
31	Fan speed control - ventilation
31	Air flow control
32	HOME LEAVE SETTING
32	Home leave (Unoccupied Mode)
33	HOLD SETTING
33	Hold
34	ADDITIONAL OPERATION – VENTILATION
34	Additional operation

35	EXTERNAL EQUIPMENT CONTROL SETTING
35	External equipment control
36	AI SMART CARE SETTINGS
36	AI Smart Care
37	EM HEAT SETTING
37	EM Heat
38	AIR PURIFY SETTING
38	Air purify
39	OVERRIDE CONTROL SETTING
39	Override control
40	SUB FUNCTION SETTING
40	Sub function entrance and setting method
41	Energy Saving Setting
42	Air purify Setting
43	Fan Auto Setting
44	Humidification setting
45	Electric Heater Setting
46	Robot Cleaning Setting
47	Ventilation kit Setting
48	Comfort Cooling Setting
49	ZONE CONTROL SETTING
49	Zone Control
50	LOCK SETTING
50	How to enter lock setting
51	Lock setting – all, on/off, mode, temperature range lock
52	TIMER SETTING
52	Timer entrance and setting method
53	Simple timer
54	Sleep timer
55	Turn-off Reservation
56	Turn-on Reservation
57	SCHEDULE SETTING
57	How to enter schedule
58	Daily Schedule
59	Schedules & Edit
60	Schedules & Edit – Add schedule
61	Exception day
62	ENERGY (Air conditioner / DX ventilator)
62	How to enter energy
63	Instantaneous power check
64	Energy consumption

66 Energy saving - Temperature Setback Timer
67 Energy saving - Time Limit Control
68 Energy setting - outdoor unit capacity setting
69 Energy setting - target instantaneous power setting
70 Energy setting - target power consumption
71 Energy setting - target operation time
72 Energy setting - Alarm Popup Setting
73 Energy setting - Usage data initialization
74 AI Energy Function - System Energy Usage
75 AI Energy Function- AI Energy Management
77 AI Energy Function- AI Energy Waste Alert

79 FUNCTION SETTING

79 How to enter function setting
80 Function Setting
82 Vane angle control setting
83 Elevation grill setting
84 Robot cleaning setting
85 Auto dry setting
86 Filter sign check and initialization
87 Prefilter Status
90 Fine Dust Filter Status
91 Change temperature setting
92 Dead Band
93 Wi-Fi Setting
95 Zone Name setting
96 Override Set Time Setting
97 Home Leave Set Temperature Setting
98 Comfort cooling setting
99 ODU Refrigerant Noise Reduction setting
100 Defrost mode setting
101 Smart load control(SLC) setting
102 Low noise mode time setting
103 Advanced fan speed "Auto" setting
104 Delay time (Ventilator)
105 Midnight air cooling (Ventilator)
106 Human detection mode setting
108 Discharge direction
109 CO2 Fan Control(general ventilator)
110 Economizer setting
111 Select Humidification Range (DX ventilator)
112 UVnano
113 Interlock air purification with AC and ventilation (ventilation)
114 AI Indoor Space Care Setting
116 Weather Info. Interlocking Control

120 USER SETTING

120 How to enter user setting
120 User Setting
121 Language setting
122 Setpoint Type Setting

123 Temperature unit setting
124 Backlight Dimming Time
125 Backlight Dimming Brightness
126 External device setting
127 External device use
127 External device types
128 On condition / Off condition
129 Date setting
130 Time setting
131 Summer time setting
132 Password setting
133 Schedule initialization
134 Theme setting
134 Humidity display
135 System restart
136 Indoor unit display light brightness setting
137 Remote Controller Button LED

138 SERVICE SETTING

138 How to enter service setting
138 Service setting
139 Service contact
140 Model information
141 RMC Version Information
142 Error history
143 Open source license

144 INSTALLATION

144 Installation of Remote Controller
146 Group control

148 INSTALLATION METHOD TO USE EXTERNAL DEVICE

148 Cable connection method to use external device

149 AIR CONDITIONER AND VENTILATION INTERFACE

150 INSTALLER SETTING

150 How to enter installer setting
151 Installer setting - air conditioner
154 Installer setting - ventilator
156 Test run setting (air conditioner / DX ventilator)
157 Central control address setting (air conditioner / general, DX ventilator)
158 ESP setting (air conditioner / general, DX ventilator)
159 Temperature sensor(2TH) setting (air conditioner / DX ventilator)
160 Ceiling height setting (air conditioner)
161 Static pressure setting(air conditioner)
162 Remote controller master / slave setting (air conditioner / General, DX ventilator)
163 Override Master/Slave setting (air conditioner / General, DX ventilator)
164 Dry contact mode setting (air conditioner / general, DX ventilator)
165 Fixed air volume (air conditioner / DX ventilator)
166 Zone Type Setting (air conditioner)


166	Zone Number Setting (air conditioner)
167	Over Heating (air conditioner)
168	Emergency heater setting (air conditioner)
169	Function control during group Control setting (air conditioner)
170	External devices of indoor unit setting (air conditioner)
171	Expand of Temperature Range (air conditioner)
172	Indoor unit address verification (air conditioner / DX ventilator)
173	Static pressure step setting (air conditioner)
174	Over Cooling (air conditioner)
175	Guard timer(air conditioner)
176	Fan speed in Cooling thermal off (air conditioner)
177	Primary heater setting(air conditioner)
178	Air conditioner Fan operation interlocked with ventilation setting (air conditioner)
179	Indoor unit Auto-Start setting (air conditioner / DX ventilator)
180	Occupancy duration time setting(air conditioner)
181	CN_CC setting (air conditioner)
182	CN_EXT setting (air conditioner / DX ventilator)
183	Outdoor unit function master setting (air conditioner / DX ventilator)
184	Fan continuous operation setting (air conditioner)
185	Low Noise Mode Priority setting (air conditioner / DX ventilator)
186	Human detection sensor (air conditioner)
187	Humidity sensing position (air conditioner)
188	ODU cycle priority (air conditioner)
190	Outdoor temp. for heating stages (air conditioner)
191	Estimated energy display (air conditioner)
192	CN_PTC setting (air conditioner)
193	Server Room (air conditioner)
196	Password initialization (air conditioner / general, DX ventilator)
197	Auto ESP (air conditioner)
199	Noise Target Control
202	Dust step color setting
202	UVnano / Filter Box
203	Fan Operation During Auxiliary Heater Only
204	Outdoor Temp Setting in Internal Heater
205	Heater Enabled by Set Temp Differential
207	Internal Heater During Defrost
208	Piping Address Setting
209	Refrigerant Leak Sensor Timer (air conditioner / DX ventilator)
210	Power Line Fault Detection
211	Product direction (general ventilator)
212	Express ventilation priority (general , DX ventilator)
213	Humidification of stand-alone ventilation mode (DX ventilator)
214	Humidification of ventilation with heating operation (DX ventilator)
215	Ventilation Fan Speed Alignment (general ventilator)
216	Filter check alarm(general ventilator)

217 GUIDE TO DIFFERENT MODE OPERATION/OPEN SOURCE SOFTWARE

217	Different mode operation
217	Open Source Software Notice Information


DESCRIPTION

NEW STANDARD REMOTE CONTROLLER



Operation display window	Operation and Settings status display
Back button	When you move to the previous stage from the menu's setting stage
Up/Down/Left/Right Button	When you change the menu's setting value
OK button	When you save the menu's setting value
On/Off button	When you turn ON/OFF the air conditioner


Accessories



DESCRIPTION OF THE OPERATION


Main screen

In the main screen, press [<, > (left/right)] button to select the category to set, and you can control by pressing [^, v (up/down)] button.



Menu screen

In the main screen, press [<, > (left/right)] button to select the menu and press [OK] button to move to menu screen.




In the menu screen, press [<, > (left/right)] button to select the category to set, and press [OK] button to move to the detail screen.




Standby Screen


When connected to a single ventilation product that can measure fine dust, it moves to the "Standby Screen" if the touch button has not been pressed for 1 minute.



Press the remote control's start/stop button in "Standby Screen" to activate or stop the product without moving screens.



If any other buttons are pressed besides the start/stop button, it moves to the main screen.



NOTE

- "Standby Screen" only works when "Auto return to main screen" is set.
- "Standby Screen" is not provided when air conditioning and ventilation are linked.
- Some information may not be displayed depending on the product.


Setting screen

Select the category to set using [^ , v (up/down)] button.



In each detail screen of the menu, as in the box in the left figure, when "<,>" icons are displayed at the same time, you can immediately apply the setting value by pressing [<, >(left/right)] button.

※ For the values that can be set in each category, refer to the detail manual for each function.




In each detail screen of the menu, as in the box in the left figure, if only ">" icon is displayed, you can move to the detail setting screen by pressing [>(right) or OK] button.

※ For the values that can be set in each category, refer to the detail manual for each function.

Popup screen

The toast message is the message displayed at the bottom of the screen when an operation is turned On/Off or if a function is set / cancelled.

The popup message is mainly displayed when an error occurred in the product.




< Toast message >




< Popup message >

Monitoring / Air Quality Level / Sub function screens

- In the main screen, you can enter the monitoring / Air Quality Level / sub function screen by pressing [Back] button and then pressing [<, >(left/right)] button.
- In the monitoring screen, you can check the indoor temperature and outdoor unit monitoring information.
 - In the sub function screen, you can turn on or off the sub function supported by the product.
 - The configuration of the screen displayed may vary depending on the version of the remote control.



- If the connected product has the Weather Info. Interlocking Control function, the outdoor weather information is also displayed on the monitoring screen.




- The outdoor weather information shows the weather, temperature, humidity, and overall fine dust quality.
- The weather is displayed in five different statuses as shown below.


Sunny	Cloudy	Rainy	Snowy	Stormy

- The outdoor overall fine dust quality shows the worse dust status value between PM 10 and PM 2.5.

- It is the function to monitor dust value measured by the dust sensor mounted inside the indoor unit.




Air conditioner Air Quality Level screen



Ventilation Air Quality Level screen

- In the air quality level screen, you can check PM 10, PM 2.5 and PM 1.0 concentration values.
- The overall index displays the worst dust status value among the three dust status values.
- If the product has the Weather Info. Interlocking Control function, the air quality information is also displayed on the Air Quality Level screen.




- The outdoor air quality is displayed as outdoor PM 10 and outdoor PM 2.5.
- If the outdoor air quality is displayed, the overall indoor air quality is not displayed.

! NOTE

- On the Air Quality Level screen of the ventilation product, outdoor shows the concentration of fine dust in the air entering the ventilation product, and flow indoors shows the concentration of fine dust in the air entering the room after passing through the filter.
- The Auto Return to Main Screen function is not run on the Air Quality Level screen.
- During group control, the Master indoor unit's information is displayed on the screen.
- The configuration of the screen displayed may vary depending on the version of the remote control.


※ Auto Return to Main Screen is a function that automatically returns to the main screen when there is no touch input for a certain period of time.

- In the sub function screen, you can turn on or off the sub function supported by the product.




Interface screen

Select the product (air conditioner or ventilation) to set using [<, >(left/right)] button.



When you control the air conditioner and the ventilation product with one remote controller, the screen is displayed as in the side figure. You can set the air conditioner by pressing [<(left)] button and pressing [OK] button to move to the air conditioner screen.



When you control the air conditioner and the ventilation product with one remote controller, the screen is displayed as in the side figure. You can set the ventilation by pressing [>(right)] button and pressing [OK] button to move to the ventilation screen.

Returning to the screen

In the main screen, after moving to the category by pressing [<, >(left/right)] button, if there is no remote controller operation, after 10 seconds, it returns to the main screen basic position. (basic position: indoor temperature display part)

In the screens except the main screen, if there is no remote controller operation for 1 minute, it moves to the main screen.

OPERATION SETTING


On / Off

Air conditioner and ventilator will be turned on or off.

Press the remote controller's ⏻ (On/Off) button.

- If the product is in operation, On/Off button will be illuminated.
- If the product is in off, On/Off button backlight will be off.

※ If the "Remote Control Button Light" menu is set to OFF in User Settings, the LED will not light up.



Operation mode

You can easily control the desired operation mode.


In the main screen, press [<,>(left/right)] button to select the operation mode or home leave or hold category, and press [^, v (up/down)] button to set the operation mode.

※ Some products may not support some operation modes.

Mode	Description
Cool	Cool the room to the desired temperature.
Dry	It removes the moisture with cooling.
Heat	Heats the room to the desired room temperature.
AI / Auto	The product automatically provides the appropriate fan speed based on the temperature of the room.
Fan	Fan only operation, no cooling or heating.
Power Cool	It provides strong cooling in short time.
Power heating	Power heating increases indoor temperature quickly.
Ice Cool Power	Ice Cool Power quickly lowers indoor temperature.

Cooling Operation

- Cooling operation’s minimum setting temperature is 18°C (16°C).
- For some types of the indoor units, the desired temperature can be controlled in the units of 1°C or 0.5°C.
- Set the desired temperature lower than the indoor temperature.
 - Indoor temperature is displayed on the default screen of the remote controller.
 - If the setpoint is set higher than the room temperature, then the unit will remain in the cool mode but will not begin to cool unit the room temperature exceeds the setpoint.
 - If you unit is operating in cooling mode and you press the [On/Off] button the cooling operation will shut off.



What is 3 minute delay function?

After the cooling stops, when the product is started right away, the reason that the cold wind does not come out is that it is the function to protect the compressor.

The compressor starts after 3 minutes and the cold wind comes out.

! NOTE

The compressor starts after 3 minutes and the cold wind comes out.


In the cooling operation, you can select the desired temperature in the range of 18°C ~ 30°C (16°C ~ 30°C).

The favorable temperature difference between the indoor temperature and the outdoor temperature is 5°C.

For some types of the indoor units, you can select the desired temperature in the range of 16°C ~ 30°C.

Heating Operation

- The heating operation’s minimum setting temperature is 16°C.
- For some types of the indoor units, the desired temperature can be controlled in the units of 1°C or 0.5°C.
- Set the desired temperature higher than the indoor temperature.
 - Indoor temperature is displayed on the default screen of the remote controller.
 - When the desired temperature is set lower than the indoor temperature, warm air doesn't come out, but for some products, the fan will recirculate room air, or stop altogether.
 - If you unit is operating in heating mode and you press the [On/Off] button the heating operation will shut off.



! NOTE

In the heating operation, you can select the desired temperature in the range of 16°C ~ 30°C.


Heating operation is operated only in cooling/heating model. The heating is not operated in cooling exclusive model.

Dry Operation

Dry operation’s initial fan speed is “Low”.

Dry operation does not have a separate desired temperature.

- If you unit is operating in dehumidification mode and you press the [On/Off] button the dehumidification operation will shut off.



! NOTE

If you use it in the rainy season, or when the humidity is high, you can have both the effective dehumidification and cooling operation at the same time.

Fan Only Operation

Fan only operation’s initial wind strength is “High”.

Fan only operation does not have a separate desired temperature.

- If you unit is operating in fan only mode and you press the [On/Off] button the the unit will stop.



! NOTE


It provides the Fan only operation without temperature control, with recirculation of indoor air.

AI / Auto operation

Auto operation’s initial desired temperature is 25°C.
The cooling exclusive model’s initial desired temperature is “It’s Fine”.
Cooling/heating model’s desired temperature can be controlled in the units of 1°C or 0.5°C.
For cooling exclusive model, the value can be controlled from “hot” stage to “cold” stage.

- Hot
- A little hot
- It’s fine
- A little cold
- Cold

- If you unit is operating in ai/auto mode and you press the [On/Off] button the ai/auto operation will shut off.




! NOTE

If the product is a cooling/heating model, in the auto operation, the desired temperature can be selected in the range of 18°C ~ 30°C.
If it does not operate as you wish, select another operation mode.

Dual setpoint auto operation

The indoor unit automatically manages room temperature with extended heating and cooling setting temperature ranges.
Dual setpoint auto mode can be set in the USER SETTING. This is recommended in North America region.



! NOTE

- Auto heating function only operates on cooling and heating models.
- Auto heating function doesn’t operate on cooling only models.
- When remote controller has a connection with indoor unit that does not support 'dual setpoint', thermal operation function of indoor unit is replaced with ON/Off control from the wired remote, when the user sets target temperatures in the below ranges.
 - cooling target temp. range : 87~99 °F (30.5~37.5 °C)
 - heating target temp. range : 40~59 °F (4~15.5 °C).

Power Cool Operation


Power cooling quickly lowers the indoor temperature.

Desired temperature: 18°C

Fan speed : Power fan speed

Fan direction: Current fan direction

- During the power cooling, if fan speed or desired temperature is changed, the power cooling is cleared, and it operates in the cooling operation mode.
- During the power cooling, if you press [On/Off] button, the power cooling operation stops, and when you press [On/Off] button again, it operates in the cooling operation mode.



Power Heat Operation


Power heating increases indoor temperature quickly.

Desired temperature: 30 °C

Fan speed: Power fan speed

Fan direction: Current fan direction

- If you adjust the fan speed or the desired temperature during power heating, the function is disabled and heating operation mode is activated.
- If you press [On/Off] button during power heating, the function stops and if you press [On/Off] button again, heating operation mode is activated.



Ice Cool Power

Ice Cool Power quickly lowers indoor temperature.

Desired temperature: 18°C

Fan Speed: Power Fan Speed

Fan direction: Current airstream direction (when it is connected to a product that supports dynamic power cooling/heating, the airstream direction will change to dynamic air current.)

- When the fan speed or the desired temperature is adjusted during Ice Cool Power operation, Ice Cool Power will be canceled and the product will operate in cooling operation mode.
- When you press the [Power] button during Ice Cool Power operation, Ice Cool Power operation will stop, and when you press the [Power] button again, the product will operate in cooling operation mode.
- The Ice Cool Power mode runs continuously for up to 1 hour.



NOTE

Depending on the version of the remote control, this function may not be activated.

OPERATION SETTING - VENTILATOR


Operation mode

Ventilation (general and direct cooling type ventilation) operation mode supports the following operation modes.

※ Some products may not support some operation modes.

Mode	Classification	Description
Auto	Ventilation operation mode – commonly supported by ventilation products	It measures the ventilation system’s indoor temperature and the outdoor temperature for the automatic operation in the optimal ventilation mode state.
Heat Exchange		It is the mode of ventilation with both supply/discharge through the heat exchanger. It is adequate to use in summer/winter where the indoor/outdoor temperature difference is big.
Bypass		It is the ventilation where the exhausted air is ventilated without going through the exchanger. It is adequate to use in spring/fall or when the indoor contamination is severe.
Cool	Air conditioner operation mode – supports direct cooling type ventilation	Cools down the room to desired temperature.
Heat		It provides warm air to the room.
Auto		The product automatically provides the appropriate fan speed based on the temperature of the room.
Stop		It stops the product’s air conditioner operation.

In the main screen, press [<,>(left/right)] button to select the operation mode category, and press [^, v (up/down)] button to set the operation mode.




※ The direct cooling type ventilation’s air conditioner operation mode is composed separately from the ventilation operation mode.

TEMPERATURE SETTING

Controlling Desired Temperature

You can easily control to the desired temperature.

- In the main screen, press [<,>(left/right)] button to select the desired temperature category, and press [^, v (up/down)] button to set the desired temperature.
 - In the cooling, heating, and AI/auto mode, the desired temperature control is possible.



Mode	Description
Cool	If the desired temperature is higher than the indoor temperature, the cooling is not performed. Set the desired temperature lower than the indoor temperature. You can select in the range of 18°C ~ 30°C (16°C ~ 30°C).
Heat	If the desired temperature is lower than the indoor temperature, the heating is not performed. Set the desired temperature higher than the indoor temperature. You can select in the range of 16°C ~ 30°C.
AI / Auto	For cooling/heating product, you can select in the range of 18°C ~ 30°C. For cooling exclusive product, you can select Hot, A little hot, Adequate, A little Cold, and Cold.




NOTE

The favorable temperature difference between the indoor temperature and the outdoor temperature is 5°C.

Check Room Temperature

You can check the current indoor temperature.

- In the remote controller's main screen, you can check the indoor temperature.



! NOTE

The temperature distribution in the remote controller installation space is not uniform, so there can be a little difference between the temperature you actually feel and the remote controller's room temperature display

According to Control type setting value


- Single setpoint
Fahrenheit: 52~99 °F
- below 52 °F: display 'LO'
- over 99 °F: display 'HI'
Celsius: 10.5~39.5 °C
- below 10.5 °C: display 'LO'
- over 39.5 °C: display 'HI'
- Dual setpoints
Fahrenheit: 34~99 °F
- below 34 °F: display 'LO'
- over 99 °F: display 'HI'
Celsius: 0.5~39.5 °C
- below 0.5 °C: display 'LO'
- over 39.5 °C: display 'HI'
- For indoor temperature below 50 °F (10 °C), the value perceived by the Thermostat(with cable) is displayed.
- Because of location of Temperature sensing, the real room temperature and the this displayed value can be different.

WIND SETTING

Fan speed control

From the main screen, press [<,>(left/right)] button to select the fan speed category, and press [^, v (up/down)] button to set the fan speed control the desired fan speed.

- It circulates in the order of Slow ↔ Low ↔ Medium ↔ High ↔ Power ↔ Auto.



※ For some product some fan speed may not be available.

Fan speed control - ventilation

You can easily control the desired fan speed.

- In the main screen, press [<,>(left/right)] button to select the fan speed category, and press [^, v (up/down)] button to set the fan speed.
- It circulates in the order of Low ↔ High ↔ Power ↔ Auto.




※ The auto Fan can be used only when the air contamination (CO₂) sensor is installed.

Air flow control

You can easily control the desired air flow

- In the main screen, press [<,>(left/right)] button to select the air flow category, and press [^, v (up/down)] button to set the air flow.
- It circulates in the order of Off ↔ Up/Down swing ↔ Left/Right swing ↔ Up/Down/Left/Right swing ↔ Swirl ↔ Indirect wind ↔ Direct wind ↔ Human detection direct wind ↔ Human detection indirect wind ↔ Smart mode ↔ Refresh mode ↔ Airflow based on activity ↔ Airflow for frequently used areas.




※ For some product some air flow settings may not be available.

HOME LEAVE SETTING

Home leave (Unoccupied Mode)

The "Home Leave" function enables proper operation of indoor unit when a space is left for a period of time.

This feature can only be used when Control type setting is set to the Dual Set Point Control mode



! NOTE


User can not change indoor unit status with wired remote controller while set 'home leave mode' except for 'home leave mode' release control.

- Home leave mode will be released if indoor unit operation was changed by commands of other controllers(central controller, drycontact and wireless remote controller).
- When occupied schedule event occurs while operate a home leave mode, home leave mode will be released and indoor unit status follow the occupied schedule event.
- Indoor unit operation change as below when the home leave mode is released.
 - The setpoints and operation mode values are reflected in the control events of the scheduled events that are currently applied.
 - If there are no schedule events, the setpoint shall be applied as last setpoints before the home leave operation.
 - If there are no setpoints before the 'home leave' operation(dehumidification or fan mode), default values will be applied to the setpoints.
 - Default values : dual setpoint auto , heat 60 °F(16 °C), cool 86 °F(30 °C)

HOLD SETTING

Hold

User can use this function when they want to manage indoor unit as home leave control mode only.



! NOTE

Can not change indoor unit status with wired remote controller while set 'hold mode' except for 'hold mode' release control.

- Hold mode will be released if indoor unit operation was changed by commands of other controllers(central controller, drycontact and wireless remote controller).
- A scheduled event is not applied to the indoor unit during a hold mode, even if a scheduled event is set.

ADDITIONAL OPERATION – VENTILATION

Additional operation

You can change the additional operation of the ventilation product.

- In the main screen, press [<,>(left/right)] button to select the additional operation category, and press [^, v (up/down)] button to set the additional operation.



Additional Operation	Description
Fast	It ventilates in short period of time. It is the function to operate the ventilation function more efficiently through the express setting which is an additional operation of the ventilation product.
Energy saving	It performs the energy saving function while ventilating efficiently.

! NOTE


The general ventilation and the direct cooling type ventilation’s additional operation are the same.
The ventilation product’s additional functions (air purify / heater / humidification / fan auto) setting methods are the same as the air conditioner.

EXTERNAL EQUIPMENT CONTROL SETTING

External equipment control

It is the function to set the contact point output of the external equipment control mode.

- In the main screen, press [<,>(left/right)] button to select the external equipment control category, and press [^, v (up/down)] button to set the contact point output.



Mode	Description
On	When it is set to “On”, it always performs the contact point output.
Off	When you set it to “Off”, it does not perform the contact point output in any case.
Auto	When it is set to “auto”, the contact point output is decided according to the user setting’s external equipment logic setting value.

! NOTE


Please use the corresponding function when the external equipment is actually connected.
When the external equipment is not set, please maintain “Off” status.
For the detail external equipment control condition setting, refer to the user setting - external equipment logic setting.

AI SMART CARE SETTINGS


AI Smart Care

This is a function that uses AI to manage the indoors pleasantly and save energy.


Press the [<, > (left/right)] buttons on the main screen to select the AI Smart Care item, then press the [V, ^ (up/down)] buttons to set.



- When the AI Smart Care runs, it is displayed on the upper left of the main screen.



- When the operation conditions do not match the AI Smart Care, the standby status is displayed as below.



! NOTE



- The AI Smart Care may not be displayed/run in some products.
- The AI Smart Care only runs when the product is cooling or heating.
- You may feel that cooling or heating are weak due to the power saving operation of the AI Smart Care.
- Set the date and time precisely for the remote control and the central controller when installing the AI engine.
- If you do not set the date and time, it may display an incorrect result value.
- The site connected to our central controller prioritizes the date and time settings of the central controller above those of the wired remote control.
- If a model for both cooling/heating, the AI Smart Care is not available during simultaneous cooling and heating operation.

EM HEAT SETTING

EM Heat

A heater is all you need to heat your space.

Use the [<, > (left/right)] buttons on the main screen to select "EM Heat", then use the [^, v (up/down)] buttons to set it to on / off.



! NOTE


- "EM Heat" may not be displayed/run in some products.
- "EM Heat" can be activated when the product is running on heating or power heating mode.

AIR PURIFY SETTING

Air purify

It cleans and makes pleasant indoor air.


1. Air purify - single operation
If air purify is turned on in operation Off state, air purify single operation is performed.



In case of air purify single operation, it operates in fan mode / automatic wind state, and the wind direction operated before the air purify single operation is turned off.

- There are 3 ways to end the air purify single operation.
- 1) Input of On/Off button during air purify single operation
 - 2) Select air purify OFF
 - 3) Change operation mode during air purify single operation

2. Air purify - additional operation




NOTE

- If mode is changed during air purify single operation, it is switched to the air purify additional operation.
- Air purify operation may not be displayed or performed in some products.

OVERRIDE CONTROL SETTING

Override control

In dual setpoint setting, wired remote controller can manages indoor unit status based on programmed control events which have occupancy option.
Override control function switches between 'occupied' and 'unoccupied', and vice-versa.
User can set timer option which can return to original schedule event in override function menu.



NOTE

- If there are no 'occupied' schedule event when operate 'override' control, wired remote controller change indoor unit operation as below default setting value.
 - operation mode : Auto
 - target temperature : 86 °F(30 °C)(cool), 60 °F(16 °C)(heat)
- If there are no 'unoccupied' schedule event when operate 'override' control, wired remote controller change indoor unit operation as 'home leave' mode default value.
 - operation mode : Auto
 - target temperature: 'home leave' target temperature.
- If wired remote controller received command from other controller, 'Override' operation will be released.
- When schedule event occurs while operating an override mode, override mode will be released and indoor unit status follow the schedule event.


SUB FUNCTION SETTING

Sub function entrance and setting method

In the menu screen, press [<,>(left/right)] button to select the sub function category, and press [OK] button to move to the sub function setting list screen.


In the sub function setting list screen, if you press [<, >(left/right)] button, you can turn on/off the corresponding sub function. (method 1)

In the main screen, press [Back] button to move to the monitoring/sub function screen, and press [<,>(left/right)] button to move to the sub function screen. In the sub function screen, select the sub function category to set, and if you press [OK] button, you can turn on/off the corresponding function. (method 2)



Energy Saving Setting

The energy saving cooling function is the function to control the desired temperature during the cooling operation to improve the comfort of the user and to improve the power saving performance.



NOTE

The energy saving function is an additional function, and it may not be displayed/operated in some products.

The energy saving function is possible only when the product is in the cooling operation.

Air purify Setting

It makes the indoor air clean and pleasant.

Sub Function	Back OK
Energy Saving	< Off >
Air Purify	< Off >
Fan Auto	< Off >
Humidification	< Off >
Electric Heater	< Off >

Monitoring	Air Quality Level	Sub Function

! NOTE
The air purify function is an additional function, and it may not be displayed/operated in some products.
If you want air purify single operation, set air purify in the wind only operation.

Fan Auto Setting

It is the function that operates the fan when the outdoor unit is running. Only indoor units with fan auto function can use this

Sub Function	Back OK
Energy Saving	< Off >
Air Purify	< Off >
Fan Auto	< Off >
Humidification	< Off >
Electric Heater	< Off >

Monitoring	Air Quality Level	Sub Function

! NOTE
The fan auto function is an additional function, and it may not be displayed/operated in some products.

Humidification setting

It is the function to activate the humidifier installed in the product when the indoor air is dry.

Sub Function	Back OK
Energy Saving	< Off >
Air Purify	< Off >
Fan Auto	< Off >
Humidification	< Off >
Electric Heater	< Off >

Monitoring	Air Quality Level	Sub Function

! NOTE
The humidification function is an additional function, and it may not be displayed/operated in some products.

Electric Heater Setting

It is the function to reinforce the heating capability by turning on the electric heater during the heating operation.

Sub Function	Back OK
Energy Saving	< Off >
Air Purify	< Off >
Fan Auto	< Off >
Humidification	< Off >
Electric Heater	< Off >

Monitoring	Air Quality Level	Sub Function

! NOTE
It can be set only in the heating operation.
The heater function is an additional function, and it may not be displayed/operated in some products.

Robot Cleaning Setting

Robot cleaning function is the function to automatically perform the filter cleaning with the cleaner in the product when the air conditioner is used for certain period of time.

Sub Function	Back	OK
Air Purify	< Off >	
Fan Auto	< Off >	
Humidification	< Off >	
Electric Heater	< Off >	
Robot Cleaning	< Off >	

Monitoring	Air Quality Level	Sub Function
		
		
		

NOTE

It can be set 30 seconds after the operation stopped.
The robot cleaning function is an additional function, and it may not be displayed/operated in some products.

Ventilation kit Setting

Function enables operation of an optional ventilation kit with indoor units

Sub Function	Back	OK
Fan Auto	< Off >	
Humidification	< Off >	
Electric Heater	< Off >	
Robot Cleaning	< Off >	
Ventilation Kit	< Off >	


Monitoring	Air Quality Level	Sub Function
		
		
		

NOTE

The ventilation kit function is an additional function, and it may not be displayed/operated in some products.

Comfort Cooling Setting

The comfort cooling is the function to automatically control the cooling strength to maintain the pleasant feeling without turning off the product after the indoor temperature reached the desired temperature.




NOTE

The comfort cooling function is an additional function, and it may not be displayed/operated in some products.
The comfort cooling function is only possible when the product is in the cooling operation.

ZONE CONTROL SETTING

Zone Control

A function to control zone with duct type indoor units.
Wired Remote controller can control maximum 8 zones.



NOTE



According to installation setting value

- If no function is supported this entry can not function.
- Old type
 - Zone control is currently only available to monitor.
- New type(4zone or 8Zone)
 - Any number of zones is installed is displayed on the screen can be controlled.

LOCK SETTING

How to enter lock setting

- In the menu screen, press [<,>(left/right)] button to select “lock setting” category, and press [OK] button to move to the lock setting list screen.
- In the lock setting list, if you press [^ , v (up/down)] button, you can turn on/off the corresponding lock function.



Lock setting – all, on/off, mode, temperature range lock

- It is the function to lock the button operation of the remote controller so that children or other persons cannot use it without permission.
- It is the function to limit the desired temperature range that can be set in the wired remote controller.

Lock	Description
All lock	It locks all button operation of the remote controller.
On/Off lock	It locks the On/Off button operation of the remote controller.
Mode lock	It locks the operation mode button operation of the remote controller.
Temperature range lock	It is the function that can limit the range of the desired temperature that can be set in the wired remote controller. - Single: Lower limit : 16~30 °C (60~86 °F) Upper limit : 16/18~30 °C (60/64~86 °F) - Dual : Cooling : 50~99 °F (10~37.5 °C) Heating : 40~90 °F (4~32 °C)




NOTE

In the central controller, when the central control temperature range lock is set, the wired remote controller’s temperature lock setting is cleared.
The temperature change by external equipment is reflected regardless of the remote controller temperature range lock.

TIMER SETTING


Timer entrance and setting method

- In the menu screen, press [<,>(left/right)] button to select the timer category, and press [OK] button to move to the timer setting list screen.
- In the timer setting list screen, press [^, v (up/down)] button to select the timer to set, and press [OK] button to move to the detail screen.
- After setting the value, when you press [OK] button, the timer is activated.
- After setting the value, if you press [Back] button, the changed value will not be applied.



Simple timer

You can easily set the timer in the range of 1~7 hours in the units of 1 hour.




NOTE

- If the product operation is On, the easy timer turns off the operation after the corresponding time.
- If the product operation is Off, the easy timer turns on the operation after the corresponding time.
- If the easy timer operation is turned On/Off before the timer operation, the set timer will be cleared.

Sleep timer

Sleep timer is the function to operate the air conditioner in sleep mode before going to sleep for certain hours and stop the operation.




! NOTE

You can set the sleep timer while the product is in operation.
If the sleep timer operation is turned On before the timer operation, the set timer will be cleared.

Turn-off Reservation

The product is automatically turned Off at the set timer time.



! NOTE

Even if the Turn-off Reservation operation is turned On/Off after the setting and before the timer operation, the set timer is not cleared.

Turn-on Reservation

The product is automatically turned On at the set timer time.

Timer	Back OK
Simple Timer	Off >
Sleep Timer	Off >
Turn-Off Reservation	Off >
Turn-On Reservation	Off >



Turn-On Reservation	Back OK
AM Hour Minute Start	
1 : 0	

! NOTE

Even if the Turn-on Reservation operation is turned On/Off after the setting and before the timer operation, the set timer is not cleared.

SCHEDULE SETTING

How to enter schedule

- In the menu screen, press [<,>(left/right)] button so select the schedule category, and press [OK] button to move to the schedule setting list screen.
- In the schedule setting list screen, press [^, v (up/down)] button to select the menu to set, and press [OK] button to move to the detail screen.

Menu	Back OK
Schedule	




Schedule	Back OK
Daily Schedule	>
Schedules & Edit	>
Exception Day	>


Daily Schedule

It is the function that can check the status of the timer (schedule) saved in the remote controller.


- In the schedule list, select the daily schedule status category, and press [OK] button to move to the detail daily schedule status screen.
- You can use the remote controller's [<,>(left/right)] button to check the timer information of other dates.



- You can use the remote controller's [^, v (up/down)] button to check the corresponding date's other timer information.



- Select the timer information, and press [OK] button to move to the corresponding timer's edit screen.




NOTE

In the daily schedule status screen, even if the timer (schedule) is set, if the corresponding date is designated as an exception date, the schedule will not be performed.
Less than 5 schedules per day is recommended.

Schedules & Edit


It is the function that can check the status of the timer (schedule) saved in the remote controller.

- In the schedule list, select the daily schedule status category, and press [OK] button to move to the daily schedule status detail screen.
- You can use the remote controller's [<,>(left/right)] button to check other date's timer information.




You can check the set timer's operation information (operation On/Off, operation mode, desired temperature), timer time, period, and day of week.

- You can edit the saved schedule's timer information.
 - Select the schedule to edit using [^, v (up/down)] button, and press [OK] button to move to the edit screen.



- Select the timer information, and press [OK] button to move to the corresponding timer's edit screen.



< If schedule is changed >


< If schedule is deleted >

Schedules & Edit – Add schedule


Description of each stage in Add schedule



Stage 1. Period setting




Stage 2. Day of week setting



Stage 3. Time setting



Stage 4. Operation setting



Add schedule is completed

- In 'Stage 1', it sets the period to perform the timer.
- In 'Stage 2', it sets the day of week to perform the timer.
- You can select 'Everyday / Weekend / Weekdays / Individual selection'.
- In 'Stage 3', it sets the start time for the timer.
- In 'Stage 4', it sets the timer operation information.
- If 'Stop' is selected, you cannot set the mode / temperature / fan speed.

When stages 1~4 are completed, along with the message of 'schedule is added', it moves to View and edit schedule screen.

Exception day

It is the function to automatically stop the operation on the set timer day.

- In the schedule list, select the exception day category, and press [OK] button to move to the Exception day designation detail screen.
- In the exception day, you can check, and add/change/delete the exception day information saved in the remote controller.
 - To add an exception day, in the Exception day registration detail screen, designate year/month/day, and press [OK] button to save the Exception day.
 - Select the Exception day to edit using [^ , v (up/down)] button, and press [OK] button to move to the edit screen.




- In the exception day edit screen, you can check, delete/change the corresponding exception day's setting contents.
- When you change the exception day information, you need to save it after the change.

ENERGY (Air conditioner / DX ventilator)

How to enter energy

- In the menu screen, press [<,>(left/right)] button to select the energy category, and press [OK] button to move to the energy list.




※ Some functions may not be available in some product types.

Instantaneous power check

It is the function that can check the product's instantaneous power.

- ※ There may be some error with the actual instantaneous power, so use it only for reference.
- In the energy list, select the "Instantaneous power" category, and press [OK] button to move to the detail screen.



- The target and the value of all can be set in the energy setting.
- The usage ratio compared to the target is the value expressed in $\text{current/target} \times 100$.
- ※ For how to set the energy, refer to the energy setting.




NOTE


Instantaneous power: It is the power currently used in the product.

Energy consumption

- You can check the energy consumption (operation time, power consumption).
- ※ There may be some error with the actual consumption, so use it only for reference.
- In the energy list, select the “energy consumption” category, and press [OK] button to move to the detail screen.



- In the detail screen, press [<,>(left/right)] button to move to the power consumption and operation time screen.




- Operation time unit is time (hr.), and power consumption unit is kWh.
- The power consumption display can be checked when it is connected to the indoor unit that supports the power consumption information display function.

List	Description	
	Power consumption	Operation time
Year On Year Usage	You can see the power consumption compared to the same month of the previous year.	You can see the operation time compared to the same month of the previous year.
Weekly usage	It displays the daily power consumption of the current month.	It displays the daily operation time of the current month.
Monthly usage	It displays the weekly power consumption of the current month.	It displays the weekly operation time of the current month.
Yearly usage	It displays the monthly power consumption of the current year.	It displays the monthly operation time of the current year.

Energy saving - Temperature Setback Timer

It is the function to return to the desired temperature after the set time after the product operation for energy saving.

- In the energy list, select “Energy saving” category, and press [OK] button to move to the energy saving screen.
- In the energy saving list, select “Temperature Setback Timer” category, and press [OK] button to move to the Temperature Setback Timer setting screen.



- When it is set to On, you can set the time (10 minutes ~ 120 minutes, 10 minutes unit) and the temperature (18°C ~ 30°C), and after the setting, when you press [OK] button, the set value is saved.
- When the desired temperature setback timer setting is set to “On”, after the set time, the desired temperature is recovered to the set temperature.


! NOTE

When it is set at the same time with the remote controller desired temperature range lock or the central control temperature range lock, it may not return to the desired temperature.

Energy saving - Time Limit Control

It is the function to stop the product operation after the set time after starting the product operation for the energy saving.

- In the energy saving list, select “time limit control” category, and press [OK] button to move to the time limit control setting screen.



- In the detail screen, you can select “On/Off” to turn on and off the time limit control function. When it is set to On, you can set the time (30 minutes ~ 540 minutes, 30 minutes unit), and after the setting, if you press [OK] button, the set value is saved. If you do not press [OK] button but press [Back] button, it moves to the list screen without saving the set value.
- If the time limit control is set to “On”, the operation stops after the set time.


! NOTE

If it is set at the same time with the remote controller operation lock, the time limit control will not be performed.

Energy setting - outdoor unit capacity setting

It is the function that can set the outdoor unit capacity.

- In the energy list, select “energy setting” category, and press [OK] button to move to the energy setting screen.
- In the energy setting list, select “outdoor unit capacity setting” category, and press [OK] button to move to the outdoor unit capacity setting screen.



- In the detail screen, you can select “On/Off” to set the outdoor unit capacity. If it is set to On, you can set the outdoor unit capacity (minimum 1kW), and after the setting, if you press [OK] button, the set value is saved. If you do not press [OK] button but press “Back’ button, it moves to the list screen without saving the set value.
- If the capacity setting is set to “On”, in the Instantaneous power screen, it is displayed as “all” capacity.
- For the outdoor unit capacity, refer to the label of the outdoor unit product.
 - For Single product and Multi product, the first 3 digits of the model name is the outdoor unit capacity.
ex) For ABC1019..., it is 10.1kW
 - For Multi-V product, the first 2 digits of the model name < 0.75 is the outdoor unit capacity.
ex) For ABCD101...., it is 10 * 0.75 = 7.5kW
- For TMS users, refer to the all capacity displayed on TMS.

NOTE


According to the user input, there may be difference to the actual product capacity.

Energy setting - target instantaneous power setting

It is the function that can set the Instantaneous power’s target value.

You can set the target value to find the power consumption status.

- In the energy setting list, select “target Instantaneous power” category, and press [OK] button to move to the target Instantaneous power setting screen.




- In the detail screen, you can select “On/Off” to set the target Instantaneous power. If it is set to On, you can set the target Instantaneous power (minimum 1kW), and after the setting, if you press [OK] button, the set value is saved.
 - If the outdoor unit capacity is set, the maximum value is the outdoor unit capacity
 - If the outdoor unit capacity is not set, the maximum value is 9999kW
If you do not press [OK] button but press “Back’ button, it moves to the list screen without saving the set value.
- When the target Instantaneous power setting is set to “On”, in the Instantaneous power screen, it is displayed as “all” capacity.

Energy setting - target power consumption

It is the function to set the target power consumption per hour.

- In the energy setting list, select “target power consumption” setting category, and press [OK] button to move to the target power consumption setting screen.




- In the detail screen, you can select “On/Off” to set the target power consumption. When it is set to On, you can set the target power consumption (minimum 1kWh, maximum 100kWh), and after the setting, if you press [OK] button, the set value is saved. If you do not press [OK] button but press “Back’ button, it moves to the list screen without saving the set value.
- If the target power consumption setting is set to “On”, it is displayed as the energy consumption’s power consumption target value.
 - Daily target consumption: Weekly usage’s daily target
 - Weekly target consumption: Monthly usage’s weekly target (daily target * 7)
 - Monthly target consumption: Yearly usage’s monthly target (daily target * 31)

Energy setting - target operation time

It is the function that can set the Instantaneous power’s target value.

You can find the power consumption status by setting the target value.

- In the energy setting list, select “target operation time” category, and press [OK] button to move to the target operation time setting screen.




- In the detail screen, you can select “On/Off” to set the target operation time. When it is set to On, you can set the target operation time (minimum 1hr. and maximum 24hr.), and after the setting, if you press [OK] button, the set value is saved. If you do not press [OK] button but press “Back’ button, it moves to the list screen without saving the set value.
- If the target operation time setting is set to “On”, it is displayed as the energy consumption’s operation time target value.
 - Daily target : Weekly usage’s daily target
 - Weekly target : Monthly usage’s weekly target (daily target * 7)
 - Monthly target : Yearly usage’s monthly target (daily target * 31)

Energy setting - Alarm Popup Setting

It is the function to set whether to use the target power consumption and the target operation time notice popup window.

- In the energy setting list, select “target operation time” category, and press [OK] button to move to the target operation time setting screen.
- In the notice popup list, select “target power consumption notice or target operation time notice” category, and press [OK] button to move to the detail setting screen.



- You can set the notice popup as “daily”, “weekly”, “monthly”. After the setting, if you press [OK] button, the setting is saved and moves to the previous screen.
- When the target power consumption notice is set to “On, daily”
If the daily target power consumption’s 80%, 90%, 95%, and 100% power is used a day, the popup screen appears.
- When the target operation time notice is set to “On, daily”
When the product is operated at the daily target operation time’s 80%, 90%, 95%, and 100%, the popup screen appears.


! NOTE

The popup message appears once every hour.

Energy setting – Usage data initialization

It is the function to initialize all of the power consumption and operation time information.

- In the energy setting list, select “consumption data initialization” category, and press [OK] button to move to the consumption data initialization setting screen.




- In the initialization popup screen, if you press “check” button, all previously saved power consumption and operation time are deleted.

AI Energy Function - System Energy Usage

This is a function that allows you to check the predicted savings from using AI Smart Care and the system's overall energy consumption.

- Press the [OK] button in the AI Energy Function item in the energy setting list to move to the Settings screen.



- Press the [OK] button in the System Energy Usage item to move to the System Energy Usage screen.

System Energy Usage			Back
You can check the total power consumption of the system (indoor and outdoor units) and the estimated savings through Smart Care.			
Period	Total Usage	Predicted Savings	
Daily	1000.0 kWh	30.0 kWh	
Weekly	2000.0 kWh	40.0 kWh	
Monthly	3000.0 kWh	60.0 kWh	
Annual	40000.0 kWh	100.0 kWh	

System Energy Usage VER.1 screen

System Energy Usage		Back
You can check the system energy saving rate through AI Smart Care		
Energy savings rate this month	Energy savings rate this year	
3.67 %	4.77 %	

System Energy Usage VER.2 screen

- When using "AI Smart Care", you can check this month/year's savings rate as calculated by the AI controller.

e.g. Daily basis

- Total usage: 1,000 kWh, Predicted savings: 30 kWh
- Total usage when reduced by using AI Smart Care: 1,000 kWh
- Expected usage when not using AI Smart Care: 1,030 kWh


NOTE

- The displayed value is the power consumption for the entire system.
- The Predicted savings are calculated by analyzing the energy usage patterns while using the AI Smart Care. For more information, refer to the LG AI engine manual or the outdoor unit installation manual.
- There may be some difference between the actual usage, so use it only as a reference
- If you need the exact usage, install an additional PDI (POWER DISTRIBUTION INDICATOR/power divider) and use it.
- The configuration of the screen displayed may vary depending on the version of the remote control and the connected product.

AI Energy Function– AI Energy Management

The AI Energy Management is a function that allows the user to set the amount of power they want to consume.

- Press the [OK] button in the "AI Energy Function" item in the energy setting list to move to the Settings screen.
- Press the [OK] button in the AI Energy Management item to move to the AI Energy Management screen.



- In "AI Energy Management" VER.1, if you press the [OK] button in "Target Setting" of the "AI Energy Management" item, it moves you to the "System Target Power Setting" screen.
- In AI Energy Management VER.2, select the month you want to set in AI Energy Management and press the [OK] button to move to the Setting System Target Energy Usage screen.

AI Energy Management			Back	OK
Check the current usage against the usage target.				
	Target Setting			
Period	Target Usage	Total Usage		
Daily	-- kWh	0.0 kWh		
Weekly	-- kWh	0.0 kWh		
Monthly	-- kWh	0.0 kWh		
Annual	-- kWh	0.0 kWh		



System Target Power Setting		Back	OK
Daily Target			
On	0 1 0 0 kWh		

AI Energy Management Screen VER.1

AI Energy Management				Back	OK
Set and check the monthly target energy usage of the system (Indoor & outdoor unit).					
Month	Target Usage	Usage	Recommended usage		
Jan.	-- kWh	-- kWh	-- kWh		
Feb.	-- kWh	-- kWh	-- kWh		
Mar.	-- kWh	-- kWh	-- kWh		
Apr.	-- kWh	-- kWh	-- kWh		



Setting System Target Energy		Back	OK
There is no last year data.			
Monthly Target(Jan.)			
On	0 1 0 0 kWh		
If you do not set the time, the function may not function normally			

AI Energy Management Screen VER.2


- Select On/Off on the detailed screen to set the target power consumption.
- When set to On, you can set the target power consumption (min 1 kWh, max 9,999 kWh). After setting, press the [OK] button to save the set value.
- If you press the [Back] button without pressing the [OK] button, to move to the list screen without saving the set value.
- On the AI Energy Management VER.2 screen, it's displayed with Recommended usage usage.

NOTE


- The displayed value is the power consumption for the entire system.
- If a target consumption that is much smaller than the daily average amount of power consumed over the past 30 days is set, the target consumption may be exceeded.
The target power setting can be reached if it falls between approximately 50% to 100% of the average amount of power consumed over the past 30 days. (0 to 50% based on the savings rate)
Example) If the average daily amount of power consumed is 100 kWh, the savings may not be more than 50 kWh even if 20 kWh is set as the power consumption target.
We do not recommend setting a target consumption of less than 50% of the average daily amount of power consumed.
- There may be some difference between the actual usage, so use it only as a reference.
- Setting too small a target as the desired level of power consumption for the system may result in poor cooling/heating performance.
- When setting the AI Energy Management function in the central controller, the Setting Target energy usage and Setting System Target Energy Usage function of the wired remote controller cannot be used.
- If a model for both cooling/heating, the AI Energy Management function is not available during simultaneous cooling and heating operation.
- The configuration of the screen displayed may vary depending on the version of the remote control and the connected product.

AI Energy Function– AI Energy Waste Alert

The “AI Energy Waste Alert” function learns the user’s usage patterns and saves power through a notification/off function when an operation pattern that is different from usual is detected. Press the [OK] button in the “AI Energy Function” item in the energy setting list to move to the Settings screen.



- Press the [OK] button in the “AI Energy Waste Alert” item to move to the Details screen.



- When setting “Energy Waste Alert” through usage, you can set “Automatic Device Shutdown” (“Use”/“Not Use”), “Notification Frequency (Frequent/Normal/Minimal)”, and “Learning Speed(Fast/Normal/Slow)”

AI Energy Waste Alert Back OK OK	
Energy Waste Alert	< Use >
Automatic Device Shutdown	< Not Use >
Notification Frequency	< Normal >
Learning Speed	< Normal >

AI Energy Waste Alert Back OK OK	
Energy Waste Alert	< Use >
Automatic Device Shutdown	< Not Use >
Notification Frequency	< Normal >
Learning Speed	< Normal >

AI Energy Waste Alert Back OK OK	
Energy Waste Alert	< Use >
Automatic Device Shutdown	< Not Use >
Notification Frequency	< Normal >
Learning Speed	< Normal >

AI Energy Waste Alert Back OK OK	
Energy Waste Alert	< Use >
Automatic Device Shutdown	< Not Use >
Notification Frequency	< Normal >
Learning Speed	< Normal >

- A pop-up window will appear when energy waste is detected. If the “Automatic Device Shutdown” setting is set to “Not Use”, a pop-up window will appear with the message, “The air conditioner is being used differently than usual. It was turned off to save energy.” If the “Automatic Device Shutdown” setting is set to “Use”, a pop-up window will appear with the message, “The air conditioner is being used differently than usual. It was turned off to save energy.”, and the operation will be stopped.
- If more than 70% of power has been used, a message saying, "The current electricity usage exceeds 70% of this month's target amount. At 100% of the target usage, the power saving mode starts and the cooling function is turned down." will be displayed in the pop-up window. After learning the AI recommended electricity amount is completed, a message saying, "To save energy, AI recommends a target amount for electricity usage. Use the AI Energy Management to achieve this target and save energy." will be displayed in the pop-up window.

NOTE


- The heater needs to have learned your usage pattern to activate the “AI Energy Waste Alert” function. This function will operate once usage pattern learning is complete.
- The higher the “Pattern learning rate” is set, the more new patterns will be learned, even if the difference from previously learned patterns is small.
- The higher the “Energy Waste Alert” is set, the faster the heater will learn new usage patterns when your usage patterns change.
- The message displayed may vary depending on your remote control version and product.

FUNCTION SETTING

How to enter function setting

To enter the menu displayed at the bottom, you need to enter the function setting menu as follows.

- In the menu screen, press [<,>(left/right)] button to select the setting category, and press [OK] button to move to the setting list.
- In the setting list, select the function setting category, and press [OK] button to move to the function setting list.



Setting Back OK OK	
Function	>
User	>
Service	>

Function Setting


Menu	Description
Vane angle control setting	You can control the wind blowing angle.
Elevation grill setting	It is the function to operate the Elevation grill for the indoor unit filter cleaning.
Robot cleaning setting	Robot cleaning function is the function to automatically perform the filter cleaning with the cleaner of the product when the air conditioner is used for certain time period. It sets the manual or automatic operation of the robot cleaning. You can set it 30 seconds after the stopping of the operation.
Auto dry setting	Auto dry function is the function to remove mold and moisture by drying the inside of the indoor unit after the cooling operation and when the product is turned off.'
Filter sign check and initialization	When it becomes the time for the indoor unit filter cleaning, the filter cleaning display appears, and it is the function to remove the display.
Prefilter Status	You can check the Prefilter Status and initialize the filter usage time.
Fine Dust Filter Status	You can check the Fine Dust Filter Status and initialize the filter usage time.
Change Temperature setting	Change Temperature is the function to set the temperature for the automatic conversion between cooling and heating according to the temperature in AI operation mode.
Dead Band	When heating and cooling desired temperatures have been changed, the set value will maintain a difference between the heating and cooling desired temperature.
Wi-Fi Setting	It is the function to perform the pairing function of the Wi-Fi module connected to the indoor.
Zone Name setting	Zone name settings allow you to select zone name.
Override set time setting	When timed override is used, the set time will be a default value.
Home leave set temperature setting	When customer operate as home leave mode, this setting temperature value will be applied.
Comfort cooling setting	It is the function to set the outdoor unit Comfort saving operation stage value.
ODU Refrigerant Noise Reduction setting	It is the function to set the outdoor unit's refrigerant noise reduction function.
Defrost Mode setting	It is the function to set the outdoor unit's defrost mode operation.

Menu	Description
Smart load control setting	It is the function to set the outdoor unit's smart load control stage value. (Smart load control is the function to calculate the necessary performance with the indoor and outdoor air temperature and humidity and operate.)
Low noise mode time setting	It is the function to set the start and end time of the outdoor unit's low noise mode operation.
Advanced fan speed "Auto" setting	It is the function to set the indoor unit's fan auto by temperature.
Delay time setting (Ventilator)	It is the function to set the ventilation operation to start after the delay time.
Midnight air cooling (Ventilator)	It is the function to discharge indoor air and supply cool outdoor air into the indoor during summer nights to save energy.
Human detection mode	It is the function to set the operation of human detection mode.
Discharge direction	This is a function to set the usage of the upper and lower vanes when operating the product.
CO ₂ fan control (General ventilator)	A function that controls the fan when the product is turned ON/OFF, based on the CO ₂ concentration in the ventilation product.
Economizer setting	Provides outside air to a room to save energy and improve the air quality indoors.
Select Humidification Range (DX ventilator)	It is the function to set the desired humidification range of DX-Type Ventilation products.
UVnano	The UVnano function uses UV LEDs to sterilize fans or filters at regular intervals when driving indoors.
Interlock air purification with AC and ventilation	AC-ventilation air purification interlock is a function that aids with indoor air purification by operating ventilation with the air purification operation of the AC when the indoor fine dust concentration is bad.
AI Indoor Space Care Setting	AI Indoor Space Care Setting is a function that makes the space comfortable by co-operating with surrounding indoor units when the desired temperature is not reached due to ambient heat load even though 100% of the heating and cooling capacity of the indoor unit is being used.
Weather Info. Interlocking Control	Weather Info. Interlocking Control is a function that operates by referring to outdoor operation information.

Vane angle control setting

You can control the wind blowing angle.

- In the function setting list screen, press [^ , v (up/down)] button to select the vane angle control category, and press [OK] button to move to the up/down vane angle detail screen.



- In the detail screen, press [^ , v (up/down)] button to select “individual control, overall control, standard”.
 - Use [< , > (left/right)] button to select the vane.
 - The selected vane is moving. Check the moving vane.
 - Press [^ , v (up/down)] button to select the desired wind angle, and press [OK] button to save the setting.
 - The wind angle’s setting range can be changed to 5 stages or 6 stages according to the product.
- ※ If you do not press [OK] button, the selected wind angle will not be reflected.

Control	Description
Each	It sets the vane angle individually.
All	It sets the vane angle of all the vanes of the product at once.
Standard	It sets the vane angle to the factory initialization state.


NOTE

For some product types, there are products with only 1 or 2 vanes.

Elevation grill setting

It is the function to operate the Elevation grill for the indoor unit filter cleaning.

- While the product operation is stopped, if you use [< , > (left/right)] button to select the setting value, the grill operation status changes.



Value	Description
Up	Raises the Elevation grill toward the product
Stop	Stops the movement of the Elevation grill
Down	Lowens the Elevation grill toward the floor

NOTE

The Elevation grill setting function may not work in some products.

Robot cleaning setting

Robot cleaning function is the function to perform the automatic filter cleaning with the cleaner of the product when the conditioner is used for certain period of time. It sets the manual or automatic operation of the robot cleaning.

- It can be set 30 seconds after the operation stop.
- You can use [<, >(left/right)] button to set the following setting values as follows.

Function	Back OK
Vane Angle Control	>
Elevation Grill	< Stop >
Robot Cleaning	< Manual >
Auto Dry	< Not Use >
Filter Sign	>

Value	Description
Auto	It automatically performs the robot cleaning when the accumulated indoor unit operation time passes 30 hours
Manual	It manually performs the robot cleaning.

NOTE

The robot cleaning setting function may not work in some products.

Auto dry setting

Auto dry function is the function to remove mold and moisture by drying inside the indoor unit after the cooling operation and when the product is turned off.

- You can use [<, >(left/right)] button to set the following setting values as follows.

Function	Back OK
Vane Angle Control	>
Elevation Grill	< Stop >
Robot Cleaning	< Manual >
Auto Dry	< Not Use >
Filter Sign	>

Value	Description
Use	Use auto dry function
Not Use	Not use auto dry function


NOTE

Auto dry setting function may not work in some products.

Filter sign check and initialization

When it becomes the time for the indoor unit filter cleaning, the filter cleaning message appears, and it is the function to remove the message.

- In the function setting list, select the Filter sign check and initialization category, and press [OK] button to display the detail screen.



Filter sign	Description
Good	Usage time is 70% or less
Normal	Usage time is 71~80%
Caution	Usage time is 81~99%
Bad	Usage time is 100%

- When it becomes time to the filter clean, “Filter cleaning or replacement is required.” message is displayed. Enter the Filter sign check and initialization detail screen.
- If the product has the function to display the time remaining until the filter cleaning, even if the filter cleaning message is not displayed, you can enter the Filter sign check and initialization.
- If there is a remaining time display function, when you enter the Filter sign detail screen, you can see the consumption and the remaining time.




! NOTE

- Some products have a Filter Time Remaining function that can be accessed with Filter Sign check.
- Dirty filters will increase the cost to cool or heat the conditioned space.
- The filter check message is cleared after certain time without a separate clearing.

Prefilter Status


You can check the Prefilter Status and initialize the filter usage time.

- Select a Prefilter Status item from the function setting list and then press the [OK] button to move to a detailed screen.




Air conditioner screen example

(The configuration of the screen displayed may vary depending on the version of the remote control and the connected product.)




Ventilation screen example




Value	Description
On	Use Auto Filter Check function
Off	Don't use Auto Filter Check function

<Models that support the Auto Filter Check filter function>


- After selecting the Auto Filter Check, use the [V, ^ (up/down)] buttons to select a setting value and press the [OK] button to apply it.
- To use the Auto Filter Check function, set the initial value, which is the initial filter status.



- If there is no initial value, change the Auto Filter Check setting to On and press the [OK] button to display the Set Initial value pop-up. Press the [OK] button to proceed with setting the Initial value. If there is already a Initial value, you can set it again through the Reset Initial Value. Setting the Initial value takes about 10 minutes



Main screen display during Auto Filter Check



Prefilter Status screen after Auto Filter Check

- When the Auto Filter Check function is set to On, the filter is automatically inspected every 720 hours to determine whether it is clogged and displays the result.
- When it's time to clean the filter, the "The filter needs cleaning or replacement" message is displayed in the pop-up window and in the monitoring information.


! NOTE

- The used and remaining amount are for reference, and the actual filter status may vary depending on the installation environment and usage conditions.
- When dust is caught in the filter, the airflow decreases and the electric bill is high, so be sure to clean or replace the filter when it is time to clean or replace it.
- After setting the initial value, do not leave the screen until the initial value setting success/failure pop-up is displayed.
- The prefilter check mark will be cleared after a certain time even if you don't specifically clear it.
- If you plan to reset it after the filter status is displayed, we recommend cleaning the filter before resetting.

Fine Dust Filter Status

You can check the Fine Dust Filter Status and initialize the filter usage time.

- Select a Fine Dust Filter Status item from the function setting list and then press the [OK] button to move to a detailed screen.



- When it's time to clean the filter, the "The filter needs cleaning or replacement" message is displayed in the pop-up window and in the monitoring information.


! NOTE

- The used and remaining amount are for reference, and the actual filter status may vary depending on the installation environment and usage conditions.
- When dust is caught in the filter, the airflow decreases and the electric bill is high, so be sure to clean or replace the filter when it is time to clean or replace it.
- The fine dust filter check mark will not be cleared unless you specifically clear it.

Change temperature setting

Change Temperature is the function to set the automatic Change Temperature between cooling and heating operation according to the temperature in AI operation mode.


- In the function setting list, select the Change Temperature category, and press [OK] button to move to the detail screen.



It is the function that can be used only in cooling/heating product.

Example of using Change Temperature

- Condition
- 1) Mode: AI mode
 - 2) temperature: 22°C
 - 3) Change Temperature: 3°C → Change Temperature 3°C difference
- ※ In case of the above conditions, it operates as in the graph.



! NOTE


The Change Temperature setting function may not work in some products.

Dead Band

Dead Band function is used with a dual setpoint mode.

When heating and cooling desired temperatures have been changed, the set value will maintain a difference between the heating and cooling desired temperature.

- In the function setting list, select the dead band category, and press [OK] button to move to the detail screen.



 **NOTE**


Dead Band function only can use in dual setpoint mode.

- When changing the desired cooling temperature, in case of that the difference with the heating temperature becomes lesser than its minimal value of difference, it lowers the desired heating temperature automatically.
- When changing the desired heating temperature, in case of that the difference with the heating temperature becomes lesser than its minimal value of difference, it raises the desired cooling temperature automatically.

Wi-Fi Setting

It is the function to perform the pairing function of the Wi-Fi module connected to the indoor unit.


- In the function setting list, select the Wi-Fi pairing category, and press [OK] button to move to the detail screen.



- In the W-Fi menu, you can set the following setting values using [<,> (left/right)] button.

Setting Value	Operation
On	Enable Wi-Fi
Off	Disable Wi-Fi

- Select the Wi-Fi pairing item and press the [OK] button to move to the details screen.






- After selecting “Apply”, if you press [OK] button, the Wi-Fi pairing popup window is created, select “check” and press [OK] button to request the Wi-Fi pairing.

NOTE

- The Wi-Fi setting function may not work in some products.
- The configuration of the screen displayed may vary depending on the remote control version and the connected product.

Zone Name setting

Zone name settings allow you to select zone name.




NOTE

Zone name setting function may not work in some indoor unit products.

Override Set Time Setting

Override Set Time function can only be used in Dual Setpoint Control mode.
When timed override is used, the set time will be a default value.




! NOTE

Override Set Time function can only be used in a dual setpoint control mode.

Home Leave Set Temperature Setting

Home Leave Set Temperature function is used in Dual Setpoint Control mode.
When customer operate as home leave mode, this setting temperature value will be applied.



! NOTE

Home Leave Set Temperature function can only be used in a dual setpoint control mode.

Comfort cooling setting

It is the function to set the outdoor unit Comfort saving operation value.

- You can set the following values using [<,>(left/right)] button.

Function	Back	OK
Comfort Cooling	< Step 1 >	
ODU Refrigerant Noise Reduction	< Step 0 >	
Defrost Mode	< Step 0 >	
Smart Load Control	Off >	
Low Noise Mode Time	Off >	

Value
Step 1
Step 2
Step 3

! NOTE

The Comfort cooling function does not work in the group control.
Comfort cooling setting function is only available in some products.

ODU Refrigerant Noise Reduction setting

It is the function to set the outdoor unit’s refrigerant noise reduction function.

- You can use [<,>(left/right)] button to set the following setting values as follows.

Function	Back	OK
Comfort Cooling	< Step 1 >	
ODU Refrigerant Noise Reduction	< Step 0 >	
Defrost Mode	< Step 0 >	
Smart Load Control	Off >	
Low Noise Mode Time	Off >	

Value	Description
Step 0	Not use
Step 1	Outdoor unit noise mode 1
Step 2	Outdoor unit noise mode 2


! NOTE

The ODU Refrigerant Noise Reduction function can be set only when the installer setting’s outdoor unit function M/S setting is set to “Master”.
ODU Refrigerant Noise Reduction function is only available in some products.

Defrost mode setting

Change the outdoor unit’s defrost mode operation.

- Select value using [<,>(left/right)] button.



Value	Step 0	Not use
	Step 1	Forced snow removal
	Step 2	Quick defrost
	Step 3	Forced snow removal + quick defrost

!

NOTE



The Defrost mode setting function can be set only when the installer setting’s outdoor unit function M/S setting is set to “Master”.

Defrost mode setting function is only available in some products.

Smart load control(SLC) setting

Change the outdoor unit’s Smart Load Control stage value.
(Smart load control is the function to calculate the indoor air temperature, outdoor air temperature, and humidity to operate effectively.)

- In the function setting list, select the Smart load control category, and press [OK] button to move to the detail screen.



Value	Off	Step 0
	On	Step 1
		Step 2
		Step 3
		Step 4

- When SLC is Operating, on the expanded screen’s monitoring information, ‘In Smart load control’ is displayed.

!

NOTE

Smart load control function can be set only when the installer setting’s outdoor unit function M/S setting is set to “Master”.


Smart load control function is only available in some products.

Step4 settings may not be available on some indoor unit products.

Low noise mode time setting

It is the function to set the start and end time of the outdoor unit’s low noise mode operation.

- In the function setting list, select the Low Noise Mode Time category, and press [OK] button to move to the detail screen.
 - After setting the start time and the end time, press [OK] button to move to the upper level list.
 - If the start time and the current time are the same, it enters the outdoor unit low noise operation mode, and in the monitoring screen, ‘in outdoor unit low noise operation mode’ message is displayed.
 - If the end time and the current time are the same, the outdoor unit low noise operation mode is cleared.



NOTE

Low noise mode time setting function can be set only when the installer setting’s outdoor unit function M/S setting is set to “Master”.
Low noise mode time setting function is only available in some products.


CAUTION

If the function is not used, please set it to Off.
When you enter the low noise operation, the cooling capacity may be degraded.

Advanced fan speed “Auto” setting

It is the function to set the indoor unit’s temperature based auto fan usage.

- It is the function to automatically change the fan speed according to the difference between the indoor temperature and the desired temperature.
- You can set the following setting values using [<,>(left/right)] button.



Value	Description
Set	Change the fan speed automatically
Clear	Do not change the fan speed automatically

NOTE

Advanced fan speed “Auto” setting function is only available in some products.

Delay time (Ventilator)

- It is the function to set the ventilation operation to start after the delay time.
- In the function setting list, select the delay time category, and press [OK] button to move to the detail screen.
 - After setting the minute, press [OK] button to move to the upper level list.

Function

Back

OK

Delay Time

Off

Change Temperature

2

Midnight Air Cooling

OK

Delay Time

Back

OK

Off

Minute

0

Value
0 ~ 60 Minutes

Midnight air cooling (Ventilator)

- It is the function to discharge indoor air and supply cool outdoor air into the indoor during summer nights to save energy.
- In the function setting list, if you select midnight outdoor air cooling category and press [OK] button, it moves to the detail screen.
 - When you set the start and end time and press [OK] button, it saves and moves to the upper level list.

Function

Back

OK

Delay Time

Off

Change Temperature

2

Midnight Air Cooling

OK

Midnight Air Cooling

Back

OK

Off

Start AM/PM

Start Hour

Start Minute

End AM/PM

AM

12

:

0

AM

NOTE

Whether to run the midnight air cooling is decided only when both air conditioner and ventilation are stopped.

- Even if it is the set midnight air cooling time, it enters the midnight air cooling only when the outdoor temperature conditions is met.
- During the midnight air cooling operation, “in midnight outdoor air cooling” message is displayed on the monitoring screen.
- Midnight air cooling function may not work in some products.


CAUTION

If you do not use the function, please set it as off.


Human detection mode setting

It is the function that enables energy saving through the human detection power saving operation and wind direction setting.


In the function setting list, select human detection operation mode category and press [OK] button to move to the lower level setting list.



After selecting human detection power saving mode category, if you press [OK] button, it moves to the detail screen.



You can select OFF $\longleftrightarrow$ On/Off Power saving $\longleftrightarrow$ Temp. control $\longleftrightarrow$ Energy-saving operation based on activity for mode value. You can set the time value when you select On/Off power saving or Temperature power saving.



After selecting human detection wind direction category, you can set the following setting values using [<,> (left/right)] button.

Value	Description
OFF	Do not use human detection wind direction control
Direct	Human detection direct wind operation
Indirect	Human detection indirect wind operation

NOTE
Human detection operation setting function may not work in some products.

Discharge direction

This is a function to set the usage of the upper and lower vanes when operating the product. You can set the following setting values using [<,>(left/right)] button.

Function	Back	OK	OK
Filter sign			✓
Change Temperature		7	>
Wi-Fi Pairing			>
Advanced fan speed "Auto"	<	Set	>
Discharge direction	<	Concurrency (whole)	>

Discharge direction	Concurrency (whole)
	Top
	Bottom

! NOTE

Discharge direction setting function may not be available on some products.

CO2 Fan Control(general ventilator)

A function that controls the fan when the product is turned ON/OFF, based on the CO2 concentration in the ventilation product.

- 1. After selecting "CO2 fan control" in the Function settings list, press the [OK] button to go to the detail screen.
- 2. After selecting "Fan control during operation on" or "Fan control during operation off" in the "CO2 Fan Control" list, you can set the following values using [<,>(left/right)] button.

Function	Back	OK	OK
CO ₂ fan control			>




CO ₂ fan control	Back	OK	OK
Fan control during operation on	<	Off	>
Fan control during operation off	<	Off	>

Condition 1	Condition 2
Operation on	Off
	Low
	Periodic
Operation off	Off
	Periodic

Economizer setting

Provides outside air to a room to save energy and improve the air quality indoors.




Value	Description
Off	Disable the economizer function to keep the outside air damper closed.
Auto	If the outside air temperature is lower than the air temperature indoors when cooling is being operated, outside air is supplied to the room to save energy.
Step 1	Opens the outside air damper opening by one stage to improve the indoor air quality by introducing fresh air into the room.
Step 2	Opens the outside air damper opening by two stages to improve the indoor air quality by introducing fresh air into the room.

! NOTE

Economizer setting function may not be available on some products.

Select Humidification Range (DX ventilator)

It is the function to set the desired humidification range of DX-Type Ventilation products. It can be set in increments of 5%.




Setting value	
Min.	20 % ~ 70 %
Max.	50 % ~ 80 %


UVnano

The UVnano function uses UV LEDs to sterilize fans or filters at regular intervals when driving indoors.

- You can use [<,>(left/right)] button to set the following setting values as follows.




Value	Description
Use	Use UVnano function
Not Use	Not Use UVnano Function



<Monitoring screen during UVnano Function "Use">

! NOTE


- The configuration of the screen displayed may vary depending on the version of the remote control.
- UVnano is a compound word of “UV” and “nanometer”.
- The UVnano function may not work on some products.
- If repair is required while using the UVnano function, the UV icon is displayed at the bottom of the Home screen. If the UV alarm is displayed, contact LG Electronics Service Center for repair.



Interlock air purification with AC and ventilation (ventilation)

AC-ventilation air purification interlock is a function that aids with indoor air purification by operating ventilation with the air purification operation of the AC when the indoor fine dust concentration is bad.

- You can set the following setting values for each category using the [<, > (left/right)] buttons.



Setting Value	Description
Use	Use interlock feature
Don't use	Don't use interlock feature


! NOTE

- If the AC's fine dust concentration is bad or very bad, ventilation is interlocked.
- Ventilation is operated at Special High Speed during interlocking operation.
- The interlocking function may not work in some products.

AI Indoor Space Care Setting

The AI Indoor Space Care is a function that makes the space comfortable by co-operating with surrounding indoor units when the desired temperature is not reached due to ambient heat load even though 100% of the heating and cooling capacity of the indoor unit is being used.


- You can use the [<, > (left/right)] buttons to set the following setting values.



<General model>

Value	Description
On	Use AI Indoor Space Care function
Off	Don't use AI Indoor Space Care function

- If a model that supports the Set Indoor Space Care manual group function, press the [OK] button to move to the AI Indoor Space Care screen.



<Models that support the Set Indoor Space Care manual group function>


Use AI Indoor Space Care (Y/N)	Description
On	Use AI Indoor Space Care function
Off	Don't use AI Indoor Space Care function

Indoor Space Search	Description
Auto	AI Indoor Space Care auto space learning
Manual (Comfort)	Set AI Indoor Space Care manual group / Set comfort first
Manual (Saving)	Set AI Indoor Space Care manual group / Set power saving first

- You can set the Search space setting item when the AI Indoor Space Care use is set to On.

Group Number	Description
00~FF	Set the Group Number when using the AI Indoor Space Care

- You can set the Group Number setting item when the Search space function is set to Manual(Comfort) or Manual(Saving).




<Main screen display when AI Indoor Space Care is running>

NOTE


- The AI Indoor Space Care finds surrounding indoor units that can co-operate through AI field learning. It needs at least two weeks for the learning period, and additional learning periods may be required depending on the operation method and environment at the installation site.
- You can operate up to 2 cooperative indoor units.
- After setting to use the AI Indoor Space Care, it is available when operating the AI Smart Care.
- The AI Indoor Space Care indoor units may be automatically turned on and off as a result of AI field learning.
- If you do not wish to use the AI Indoor Space Care function, set it to Not use. For models that support the Set Indoor Space Care manual group function, set to Off.
- If a model for both cooling/heating, the AI Indoor Space Care is not available during simultaneous cooling and heating operation.

Weather Info. Interlocking Control

The Weather Info. Interlocking Control is a function that operates by referring to outdoor operation information.
Select the Weather Info. Interlocking Control from the function setting list and press the [OK] button to move to the lower settings list.




In the lower settings list, you can set the settings for comfort "Comfort operation with humidity reference", "Preheating mode Schedule", and "Set Snow Removal Mode".
- The Comfort Operation With Humidity Reference is a function that uses the outdoor humidity to actively save power for when the outdoor unit is running.
After selecting the Comfort Operation With Humidity Reference item, you can use the [<,> (left/right)] buttons to set it as follows.



Value	Description
Not Use	Don't use Comfort Operation With Humidity Reference
Use	Use Comfort Operation With Humidity Reference

- The Preheating Mode Schedule is a scheduling function that shortens the time to reach a comfortable temperature by warming up the indoor space before actual use.
Select the Preheating Mode Schedule item and press the [OK] button to move to the lower settings list.




Value	Description
Inactivated	Disable Preheating Mode Schedule
Activated	Enable Preheating Mode Schedule


- After selecting the item to enable the schedule, you can use the [<,> (left/right)] buttons to set it as follows.

Select the Set Date item and press the [OK] button to move to the Set day screen.


- You can easily select specific Customize/Everyday/weekdays/weekend.




- If you want to set the specific day, you can move to the day you want and press the [OK] button to select/deselect any day.



- Use the [> (right)] button to select the check box and press the [OK] button to finish setting it.



- Select the Set time item and press the [OK] button to move to the Set time screen.
- After selecting the start and end time, press the [OK] button to set the Preheating Mode Schedule time.




! NOTE

- When the Preheating Mode Schedule is running, it is displayed in the monitoring information.

The Set Snow Removal Mode setting is a function to set whether to operate the outdoor fan when it snows to remove the snow.

- After selecting the Set Snow Removal Mode item, you can use the [<,> (left/right)] buttons to set it as follows.




Value	Description
Not Use	Don't use Set Snow Removal Mode
Use	Use Set Snow Removal Mode

USER SETTING

How to enter user setting

To enter the menu displayed at the bottom, you need to enter the user setting menu as follows.

- Select the setting category, and press [OK] button to move to the setting list.
- Select the user setting category, and press [OK] button to move to the user setting list.



User Setting



- You can set the product user functions.
- Some functions may not be available in some product types.

Menu	Description
Language setting	Set the language to be displayed on the remote controller.
Setpoint Type Setting	It is the function to set GUI type on the remote controller.
Temperature unit setting	Set the temperature unit displayed on the remote controller.
Backlight Dimming Time	This function sets the remote control's brightness adjustment time.
Backlight Dimming Brightness	This function sets the brightness when adjusting the remote control's screen.
External device setting	Set the name of external equipment and equipment logic setting
Date setting	Set the date displayed on the remote controller.
Time setting	Set the time displayed on the remote controller.
Summer time setting	Set the summer time in the remote controller.
Password setting	Set the password to prevent unauthorized change to remote controller settings.
Schedule initialization	Initialize all timer settings in the remote controller.
Theme setting	Set the theme of the remote controller screen.
Humidity display	It is the function to decide whether to display humidity on the main screen and additional information screen.
System reboot	Restart the remote controller.
Indoor unit display light brightness	This function adjusts the brightness of the indoor unit display light.
Remote Controller Button LED	This function allows you to turn the remote control's [Power] button LED on or off.

Language setting

Set the language to be displayed on the remote controller.

- In the user setting list, select the language category, and press [OK] button to move to the detail screen.
- After the setting, if you press [OK] button, the setting is saved and moves to the previous screen.





Language		
한국어	English	Français
Deutsche	Italiano	Español
Русский	Polski	Português
中文	Čeština	


Setpoint Type Setting

It is the function to set GUI type on the remote controller.

- * Dual setpoint type is a function that makes it possible to set the cooling and heating target temperature simultaneously. It is recommended for customers accustomed to using North American thermostats.
We recommend that you use it only in the region (North America).
If select dual setpoint option, target temperature ranges will be expanded and activated override, home leave, hold mode and occupancy information based schedule.



<Dual setpoint>





<Single setpoint>

Temperature unit setting

Set the temperature unit displayed on the remote controller.

- In the user setting list, select the temperature unit setting category, and press [OK] button to move to the detail screen.



Value	Celsius	1°C
		0.5°C
	Fahrenheit	



CAUTION

The temperature unit function may not work or work differently in some products.
You cannot set the temperature unit in the slave wired remote controller.

Backlight Dimming Time

This function sets the remote control’s brightness adjustment time.

- Select the following setting values using [<,>(left/right)] button.

User	Back OK
Language	English >
Setpoint type	< Single >
Temperature Unit	Celsius, 1°C >
Backlight Dimming Time	< 30 s >
Backlight Dimming Brightness	< 10% >

Value		
15sec	30sec (default)	1min

CAUTION

If the set value is used for one minute, the LCD life may be reduced.

Backlight Dimming Brightness

This function sets the brightness when adjusting the remote control’s screen.

- Select the following setting values using [<,>(left/right)] button.

User	Back OK
Setpoint type	< Single >
Temperature Unit	Celsius, 1°C >
Backlight Dimming Time	< 30 s >
Backlight Dimming Brightness	< 10% >
External Device	>

Value				
0%	10% (default)	20%	30%	Auto

CAUTION

If the set value is used at 30 %, the LCD life may be reduced.

- ※ "Auto" setting is only available in the indoor units that is equipped with the human detection sensor.
- ※ When set to Auto, the wired remote control brightness (0 %, 10 %, 20 %, 30 %) is automatically adjusted according to the light intensity detected by the human body sensor.

External device setting

- Set the name of external equipment and equipment logic setting
- In the user setting list, select the external device setting category, and press [OK] button to move to the detail screen.

User	Back	OK
Backlight Dimming Brightness		
External Device	>	
Date	2022.6.22(Wed.) >	
Time	AM 11:49 >	
Summer Time	Off >	



External Device	Back	OK
External Device Use	< Use >	
External Device Type	< Heater >	
On Condition	Temperature is 2° over >	
Off Condition	Indoor Device On >	

External device use

- In the external device setting list, select “External device use” category, and press [OK] button to move to the external device use setting screen.
 - If external device use setting value is use, you can see the control unit of external device in main screen.

External Device	Back	OK
External Device Use	< Use >	
External Device Type	< Heater >	
On Condition	Temperature is 2° over >	
Off Condition	Indoor Device On >	

Value	
Not use	Use

External device types

- It is the function to set the name of the External device attached to the remote controller.
- You can set the following setting values using [<,>(left/right)] button.

External Device	Back	OK
External Device Use	< Use >	
External Device Type	< Heater >	
On Condition	Temperature is 2° over >	
Off Condition	Indoor Device On >	

Value					
Motor	Lighting	Fan	Heater	Pump	Others

On condition / Off condition

It is the function to set to use the information managed by the wired remote controller as the contact point control condition to widen the usage of the contact point (Digital Output) installed in the remote controller.

- In the external device setting list, select the On/Off condition setting category, and press [OK] button to move to the detail screen.

External Device

Back

OK

External Device Use

< Use >

External Device Type

< Heater >

On Condition

Not Use >

Off Condition

Not Use >

OK

On Condition

Back

OK

Condition

Control

None

-

-

--

Condition 1	Condition 2	Condition 3	Condition 4
None	Deactivate	-	Deactivate
Aircon	On	-	External device name On External device name Off
	Off	-	
	Cool mode	-	
	Heat mode	-	
	Fan mode	-	
	Dry mode	-	
	Auto mode	-	
Current Temp.	1°C~ 39.5°C	Over	
		Under	

- The External device operates as the operation set in the conditions 1~3.
- If the External device is set to auto while both ON condition and OFF condition are not set, contact point OFF is output.
- If the ON condition and OFF condition are the same, it is finally processed as OFF condition.

Date setting

Set the date displayed on the remote controller.

- In the user setting list, select the date category, and press [OK] button to move to the detail screen.
- After the setting, if you press [OK] button, the setting is saved and moves to the previous screen.

User

Back

OK

External Device

>

Date

2016.5.18(Wed.) >

Time

PM 02:02 >

Summer Time

Off >

Password

Off >

OK

Date

Back

OK

Month

Day

2016

5

18

Time setting

Set the time displayed on the remote controller.

- In the user setting list, select the time category, and press [OK] button to move to the detail screen.
- After the setting, if you press [OK] button, the setting is saved and moves to the previous screen.

UserBackOKOK

External Device

Date2016.5.18(Wed.)>

TimePM 02:04>

Summer TimeOff>

PasswordOff>

OK

TimeBackOKOK

<PM>HourMinute

2:5

Summer time setting

Set the daylight savings time dates in the remote controller.

- In the user setting list, select the summer time setting category, and press [OK] button to move to the detail screen.
 - Summer time: The system to advance the time by 1 hour from the spring when the day is longer and return back in the fall when the day gets shorter.
 - When it becomes AM 02:00 on the DST start date, the current time changes to AM 03:00, and when it becomes AM 02:00 of the DST end date, the current time changes to AM 01:00.

UserBackOKOK

External Device

Date2016.5.18(Wed.)>

TimePM 02:05>

Summer TimeOff>

PasswordOff>

OK


Summer TimeBackOKOK

<Off>MonthDayMonthDay

11-11


Password setting

- Set the password to prevent unauthorized change to remote controller settings.
- Select the user password setting category, and press [OK] button to move to the detail screen.
 - If the password is set, when you enter “menu – setting”, you need to input password to enter the setting list.
 - When you forgot the password, you can initialize the password using the installer setting’s “password initialization”.
The initialized password is “0000”.



Schedule initialization


- Initialize all timer settings in the remote controller.
- In the user setting list, select the schedule initialization setting category, and press [OK] button to move to the detail screen.
 - Press the check button to initialize the sleep/simple timer, on/off timer, schedule and exception date in the remote controller.



Theme setting

Set the theme of the remote controller screen.


- Select either white or black using [<,>(left/right)] button.



Humidity display

It is the function to decide whether to display humidity on the main screen and additional information screen.

You can use [<, > (left/right)] button to set the setting values (On or Off).



Setting value	ON	Display humidity.
	OFF	Do not display humidity.

NOTE



If humidity display is `ON`, the displayed humidity is different according to the humidity detection location setting (installer setting).

- Remote controller: remote controller humidity display.
- Indoor unit: If it receives indoor unit humidity, it displays the indoor unit humidity, and if it does not receive indoor unit humidity, it does not display humidity.

System restart

Restart the remote controller.

- In the user setting list, select the system restart setting category, and press [OK] button to move to the detail screen.
 - In the detail screen, when you press [OK] button, a popup message is displayed, press the check button, to restart the system.
 - For forced reset, press down [On/Off + Back] button for 5 seconds to restart the system.



Indoor unit display light brightness setting

This function adjusts the brightness of the indoor unit display light.

- You can set the following setting values using [<,>(left/right)] button.

User	Back	OK
Theme	< White >	
Humidity display	< On >	
Auto return to main screen	< On >	
Indoor unit display light brightness	< Off >	
System Reboot	>	

Value		
On	Off	Auto

- ※ "Auto" setting is only available in the indoor units that is equipped with the human detection sensor.
- ※ When set to Auto, the indoor unit display light brightness will automatically adjust according to the illuminance detected by the human detection sensor.
- ※ "Off" setting is only available in the indoor units that have brightness control function.

Remote Controller Button LED

This function allows you to turn the remote control's [Power] button LED on or off.

- Use the [<,>(left/right)] buttons to change the setting.

User	Back	OK
Auto return to main screen	< On >	
Air Conditioner Display Brightness	< 100% >	
Remote Controller Button LED	< On >	
System Reboot	>	
Region Selection	>	

Value	Operation
On	When the product starts operating, the [Power] button LED turns on, and when it stops, the [Power] button LED turns off.
Off	LED OFF

!

NOTE


Depending on your remote control version, this function may not be activated.

SERVICE SETTING

How to enter service setting

To enter the menu displayed at the bottom, you need to enter the service setting menu as follows.

- In the menu screen, press [<,>(left/right)] button to select the setting category, and press [OK] button to move to the setting list.
- In the setting list, select the service setting category, and press [OK] button to move to the service setting list.



Service setting




- You can set the product service functions.
- Some functions may not be displayed/operated in some product types.

Menu	Description
Service contact	Check and input the service center phone number that you can call when there is service issue.
Model Information	Check the indoor/outdoor product group and capacity information to which the remote controller is connected.
RMC Version Information	Check the remote controller model name and software version.
Error History	View the connected indoor unit's error history.
Open Source License	View the remote controller's open source license.

Service contact

Check and input the service center phone number that you can call when there is service issue.


- In the service setting list, select the service contact point and press [OK] button to move to the detail screen.
- While “edit” button is selected, press [OK] button to move to the edit screen, change it, and press [OK] button to change the service contact point.



Model information

Check the indoor/outdoor product group and capacity information to which the remote controller is connected.


- In the service setting list, select the indoor/outdoor model information category, and press [OK] button to move to the detail screen.
- Indoor unit capacity
 - 1kWh = 1kBtu * 0.29307
 - kWh is the result calculated based on Btu, There may be a small difference between calculated and actual capacity.
 - Ex) If the indoor unit capacity is 18kBtu, it is displayed as 5kWh.



RMC Version Information

Check the indoor/outdoor product group and capacity information to which the remote controller is connected.

- In the service setting list, select the remote controller version information check category, and press [OK] button to move to the detail screen.



Error history

View the connected indoor unit’s error history.

- In the service setting list, select ‘check error history’ category, and press [OK] button to move to the detail screen.
 - You can view up to 20 error instances sorted by date occurred.

ServiceBackOKOK

Service Contact>

Model Information>

RMC Version Information>

Error History>

Open Source License>

OK

Error HistoryBack

06.19 21:152

06.19 14:102

06.19 14:082

06.19 14:042

Open source license

View the remote controller’s open source license.

- In the service setting list, select the open source license category, and press [OK] button to move to the detail screen.

ServiceBackOKOK

Service Contact>

Model Information>

RMC Version Information>

Error History>

Open Source License>

OK

Open Source LicenseBack

LGE Open Source Software Notice

Product Type	HVAC WIRED REMOTE CONTRC
Model Number/Range	RS3 Wired Remote Controller


Those products identified by the Product Type and Model Range above from LG Electronics, Inc. ("LGE") contain the open source software detailed below. Please refer to the

1/401


INSTALLATION

Installation of Remote Controller


- After fixing the remote controller installation plate on the desired location, fix it firmly with the provided screws.
 - If the installation plate is not flat on the surface, it may result in the controller being twisted and cause a defect.
 - If there is a mounting box, install the remote controller installation plate using the fixings holes which suit, as in the below diagrams.
 - Do not leave a gap with the wall or product loose after the installation.



- The wired remote controller cable can be installed in 4 directions. Install to the suitable direction according to the installation environment.
 - Installation direction: Rear entry, top side, right side, left side.
 - When you install the remote controller cable at the top, right and left side, remove the remote controller cable guide hole before the installation.
 - ※ Use a long nose pliers to remove the guide hole.
- After removing the hole, trim the cut surface neatly.



- When installing the remote control cable on the left side, be sure to install it in the following guide.
 1. Make the cable to "┐" shape as shown below.
 2. Fit the bent "┐" cable into the upper center piece of case.
 3. Tighten the installation plate with preventing interference with the surrounding guide structure.
 - ※ If the cable is assembled in a shape other than "┐", it may not be fastened to the installation plate due to interference with the structure of case.




Reference. the bent cable shape



The Upper center boss for fixing the bent cable

- After fixing the remote controller top side on the installation plate attached to the wall as in the following figure, press the bottom side to combine with the installation plate.
 - Do not leave a gap in the top, bottom, left, and right side of the remote controller and the installation plate after combining them.
 - Before combining with the installation plate, arrange the cables to avoid interference with the circuit parts.

<Order of Combining>




- When you remove the remote controller from the installation plate, insert a small flat head screwdriver into the bottom side separation hole and turn clockwise to separate the remote controller.
 - There are 2 separation holes at the bottom part. Slowly separate one by one.
 - Be careful not to damage the internal parts during the removal.

<Order of Separation>



- Use the connection cables to connect the indoor unit with the remote controller.

DC 12 V	Red
Signal	Yellow
GND	Black



- For the following cases, separately purchase and use the cables suitable for the situation.
 - Do not install the cable over 50 m. (It may cause communication issues.)
 - If the distance between the wired remote controller and the indoor unit is 10 m or more : 10 m extension cable (model name: PZCWRC1)
 - If you control several indoor unit products with one wired remote controller : Group control cable (model name: PZCWRG3)

! NOTE

During the wired remote controller installation, do not bury it in the wall. (It may cause temperature sensor failure.)


Do not install the cable over 50 m. (It may cause communication defect.)

When you install the extension cable, carefully check the direction of the connectors on the remote controller side and the product side before the installation.

Specification of extension cable: AWG 24, 3 conductor or above.

Group control

- It connects and controls 2 or more air conditioner indoor units(Maximum number of IDU : 16ea) to one wired remote controller.
- ※ Connect using the group control cable.



- ① Group control cable (PZCWRCG3): Connect to indoor unit’s wired remote controller connector
- ② Extension cable (PZCWRC1): Connect to No. ① cable and slave indoor unit’s wired remote controller connector

While No. ① cable is connected, connect No. ② cable.




NOTE

- Connect only GND and signal cable to the indoor unit set as slave. (If power cable is also connected, it may cause loss of communication)
- Inquiries related to the purchase of the cable shall be directed to the specialized company and the service center.


Change master/slave of the indoor unit.

- For ceiling cassette and duct product group, change the setting with the indoor unit PCB switch.



- For the details on the wireless remote controller master/slave setting changes, refer to the wireless remote controller manual.
- After completing the master/slave setting in the indoor unit product, turn Off the power of the indoor unit product, and turn On the power after 1 minute.

- You can use two wired remote controllers for one indoor unit.
 - A dedicated cable must be used for the connection. If necessary, use an extension cable additionally and install. (2-Remo cable : PZCWRC2, Extension cable : PZCWRC1)
 - For normal operation, one should be set as master and the other as slave. (Refer to the function "Installation setting - RMC master/slave")
 - After completing the RMC master/slave setting, turn off the power of indoor unit, and turn on the power after 1 minutes.
 - You cannot control the group as shown in the right for some products.



NOTE

- During the group control, set only 1 indoor unit as master.
- During the group control, some functions other than the basic operation setting, fan speed Low/Med/High, remote controller lock setting, and time setting may be limited.
- During the individual control, if the master indoor unit Dip switch is set to slave, malfunction may occur.


INSTALLATION METHOD TO USE EXTERNAL DEVICE

Cable connection method to use external device

- 1) Wired remote controller-cable connection method.
 - In the wired remote controller, connect the part marked in the following figure (J02C, DO-Port) to the cable.
 - According to the installation environment, there are 3 directions (Rear entry, top side, and right side) for the installation.
- 2) Cable extension connection method
 - Among the cables connected to the wired remote controller, cut the remaining connectors on the other side, and then extend and connect the cables
 - Extension cable specification: 24~26AWG.

CAUTION

For the External device connection, use the cable insulated with sheath for the extension connection.
Before combining with the installation plate, arrange the cables to avoid interference with the internal parts.



- Output specification
 - Voltage : DC 11~12V
 - Current : 30mA

AIR CONDITIONER AND VENTILATION INTERFACE

- It controls using the wired remote controller at a place where the air conditioner indoor unit and the ventilation product are connected and installed at the same time.
 - When the power is applied, the remote controller recognizes the product and operates normally.

	Independent operation	Interfaced operation
General ventilation	[general ventilation independent operation]	[General ventilation interfaced operation]
Direct ventilation	[Direct ventilation independent operation]	[Direct ventilation interfaced operation]

- ※ The wiring method is the same as the air conditioner user manual. (Refer to the remote controller manual group control page contents)
- ※ Ventilation product means general ventilation product and direct cooling type ventilation product.

INSTALLER SETTING


How to enter installer setting

!

CAUTION

The installer setting mode is the mode to set the remote controller’s detail function. If the installer setting mode is incorrectly set, it may cause product failure, user’s injury, or property damage. It must be set by the installation specialist with the installation license, and if it is installed or changed without installation license, all problems caused will be the responsibility of the installer, and may void the LG warranty.

- In the menu screen, press [<,>(left/right)] button to select the setting category, and press [^ (up)] button for 3 seconds to enter the password input screen for the installer setting.
- Input the password and press [OK] button to move to the installer setting list.



※ Installer setting password
Main screen → menu → setting → service → RMC version information → SW Version
Example) SW version : 1.00.1 a
In the above case, the password is 1001.

!

NOTE

Some categories of the installer setting menu may not be available depending on the product function or the menu name may be different.

Installer setting – air conditioner

- You can set the product user functions.
- Some functions may not be displayed/operated in some product types.

Menu	Description
Test run setting	It is the function to set the trial operation at the initial product installation.
Central control address Setting	It is the function to set the central control address of the indoor unit during the central controller connection.
ESP setting	It is the function to set the wind amount value corresponding to each wind amount for easy installation.
Temperature sensor setting	It is the function to select the temperature sensor that will decide the indoor temperature.
Ceiling height setting	It is the function to control the wind amount stage according to the ceiling height for the ceiling type products.
Static pressure setting	The fixed pressure setting can be set only in the duct products. It cannot be set in other products.
RMC master/slave setting	It is the function to set group control or 2-remote controller control.
Override master/slave setting	The operation master / slave selection function is to avoid other mode operations, and it is the function to prevent the selection of the opposite mode of the indoor unit set as master by the indoor units set as slaves.
Dry contact mode setting	Dry contact function is the function that can be used only when the dry contact devices is separately purchased and installed.
Fixed air volume	It is the function to apply different fan speeds automatically for each thermal control status.
Zone Type Setting	It is possible to setup zone new type or old one of the product which is available to install the damper controller.
Zone Number Setting	Zone Number is to set the number of installed zones. It's possible to control only in zone new type.
Over Heating	Provides an adjustable deadband around the heating setpoint through selectable heating thermal on/off values.
Emergency Heater setting	It is the function to set whether to use emergency heater control function and the usage environment.
Func. control during grp. Control setting	It is the function to set common functions or some functions to be controlled by the master indoor unit standard during the group control.
Power Line Fault Detection	This function is designed to protect the product when a fault is detected in the power supply.

Menu	Description
External devices of indoor unit setting	It is the function to set whether to mount option unit (Air purify / Humidification / Heater / Ventilation / Elevation grill / Aux Heater / Refrigerant leakage detection sensor) when it is additionally installed or removed after the mass production.
Expand of Temperature Range	This function is used for select setting temperature range option.
Indoor unit address verification	This function allows you to check the address of the indoor unit designated by the outdoor unit.
Static pressure step setting	This is the function that static pressure of the product is divided in 11 steps for setting.
Over Cooling	Provides an adjustable deadband around the cooling setpoint through selectable cooling thermal on/off values
Guard timer	It is a function that sets the minimum running time of outdoor unit cycle mode when switching from cooling mode to heating mode and vice versa during Auto Operation mode.
Fan speed in Cooling thermal off	It is a function that sets the indoor unit fan movement, in cooling mode, when thermal is off.
Primary heater setting	It is the function to set the heater usage to have higher priority over the outdoor unit cycle during the indoor unit heating operation.
Air conditioner Fan operation interlocked with ventilation setting	It is the function to set whether to operate the air conditioner fan during the interface operation of the air conditioner and the ventilation product.
Indoor unit Auto-Start setting	It is a function that sets whether to restore the indoor unit operation by resuming the previous power-on state or as power-off state in the power failure compensation.
Occupancy duration time setting	It is the function to set the occupied decision maintaining time among the occupied sensor values.
CN_CC setting	It is the function to set whether to install (use) Dry Contact. (It is not a function for Dry Contact installation, but it is a function to set the usage of the indoor unit's CN_CC port.)
CN_EXT setting	It is the function to set the indoor unit's Dry Contact Port to control external input and output according to DI/DO set by the customer. (It is the function to decide the usage of the contact point port (CN_EXT) mounted in the indoor unit PCB.)
ODU function master setting	It is the function to set the outdoor unit's function Master / Slave.
Fan continuous operation setting	It is the function to set the indoor unit's continued Fan function usage. It is the function to maximize the cooling/heating efficiency by the outdoor unit operating the indoor unit fan operation longer than the previous operation method.

Menu	Description
Low noise mode priority setting	It is the function to set the main agent of the low noise mode control. (It is the function to set only one of the outdoor unit / remote controller can control the low noise operation.)
Human detection sensor setting	It is the function to set whether to install human detection sensor and operation standard value.
Humidity sensing position	It is the function to set the location to detect humidity.
ODU cycle priority	This function can select standby mode or priority cooling.
Outdoor temp. for heating stages	This function can select outdoor temperature values for use reference point of heater and heating mode operation.
Estimated energy display	This function can set to display energy data which ODU estimated.
CN_PTC setting	This is a function to set PTC Port of indoor unit.
Password initialization	It is the function to initialize (0000) the password when you forgot the password set in the remote controller.
Auto ESP	This function automatically sets the rotation speed of the fans corresponding to each step of rated airflow for easy installation.
Dust step color setting	This function is to set the dust step color.
UVnano / Filter Box	It is the function to set whether to mount option unit (UVNano/Filter box) when it is additionally installed or removed after the mass production
Fan Operation During Auxiliary Heater Only	This is a function to set the indoor unit fan to be used even when the Auxiliary heater is operating alone.
Server Room	This is a function to set alternating and backup operation to keep the temperature of the server room stable.
Noise Target Control	The Noise Target Control function is a function that limits the noise caused by the outdoor unit running.
Outdoor Temp Setting in Internal Heater	This function sets the outdoor temperature at which the internal heater is activated.
Heater Enabled by Set Temp Differential	This function sets the Thermo On/Off temperature between the room temperature and the desired temperature when the heater is operating.
Internal Heater During Defrost	This function keeps the internal heater in use during defrosting.
Piping Address Setting	This feature sets the piping address of the "Multi" series.
Refrigerant Leak Sensor Timer	This feature resets the life timer of the refrigerant leakage detection sensor.

Installer setting - ventilator

- You can set the product user functions.
- Some functions may not be displayed/operated in some product types.


Menu	Applied products	Description
Test run setting	DX(Direct Exchanger) Type	It is the function to set the trial operation at the initial product installation.
Central control address Setting	General	It is the function to set the central control address of the indoor unit during the central controller connection.
Air supply ESP	General/DX Type	It is the function to set the fan speed value corresponding to the air supply side fan speed.
Air discharge ESP		It is the function to set the fan speed value corresponding to the air discharge side fan speed.
Temperature sensor setting	DX Type	It is the function to select the temperature sensor that will decide the indoor temperature.
Product direction	General	It is the function to set the ventilation indoor unit's installation direction.
Express ventilation priority	General/DX Type	It is the function to set the priority of the air supply and discharge during the express ventilation operation.
RMC master/slave setting		It is the function to set group control or 2-remote controller control.
Override master/slave setting	DX Type	The operation master / slave selection function is to avoid other mode operations, and it is the function to prevent the selection of the opposite mode of the indoor unit set as master by the indoor units set as slaves.
Dry contact mode setting	DX Type	Dry contact function is the function that can be used only when the dry contact devices is separately purchased and installed.
Fixed fan speed setting	DX Type	It is the function to set the indoor unit's fan speed option to variable or fixed.
Hum. Of Stand-alone Vent. Mode	General/DX Type	It is the function to set whether to use the humidification function in the direct cooling type ventilation's ventilation single operation.
Hum. Of Vent. With Heating Oper.	DX Type	It is the function to set the direct cooling type ventilation's heating humidification function as auto or manual.

Menu	Applied products	Description
Vent. Fan Speed Alignment	General	It is the function to increase/decrease ventilation's standard fan speed from the current status according to the field environment.
Indoor unit address verification	DX Type	This function allows you to check the address of the indoor unit designated by the outdoor unit.
Indoor unit Auto-Start setting	DX Type	It is a function that sets whether to restore the indoor unit operation by resuming the previous power-on state or as power-off state in the power failure compensation.
CN_EXT setting	DX Type	It is the function to set the indoor unit's Dry Contact Port to control external input and output according to DI/DO set by the customer. (It is the function to decide the usage of the contact point port (CN_EXT) mounted in the indoor unit PCB.)
ODU function master setting	DX Type	It is the function to set the outdoor unit's function Master / Slave.
Low noise mode priority setting	DX Type	It is the function to set the main agent of the low noise mode control. (It is the function to set only one of the outdoor unit / remote controller can control the low noise operation.)
Filter check alarm	General	This function sets the filter check alarm of the ventilation product.
UVnano	General ventilation	This function sets whether or not UV LEDs are installed in order to use the Uvnano function.

Test run setting (air conditioner / DX ventilator)

After product installation, the Test run must be performed. For Test run related details, refer to the product manual.


- In the installer setting list, select the Test run setting category, and press [OK] button to move to the detail screen.
 - You can select 'cooling Test run / heating Test run'
 - During the Test run, if you start the following functions, the Test run stops.
☞ Operation mode, desired temperature, fan speed, wind direction, start/stop



Central control address setting (air conditioner / general, DX ventilator)


It is the function to set the central control address of the indoor unit to allow communication with a central controller,

- In the installer setting list, select the central control address setting category, and press [OK] button to move to the detail screen.
- Select a hex value between 00 and FF.
Value 1: group address setting / value 2: indoor unit address setting



ESP setting (air conditioner / general, DX ventilator)

It is the function to set the fan speed value corresponding to each fan speed for easy installation.



! NOTE
If ESP is incorrectly set, the air conditioner may malfunction.
This function must be set by the installation specialist that holds an installation license.
For ventilation products, separate ESP values are used for the supply and exhaust fans.

- In the installer setting list, select the ESP setting category, and press [OK] button to move to the detail screen.


Product	ESP fan speed	value
Air conditioner	Slow	0 ~ 255
	Low	
	Med	
	High	
	Power	
Ventilation	Low	
	High	
	Power	

! NOTE
Be especially careful not to switch ESP values corresponding to each fan speed.
Engineering manuals have ESP setting tables that reference air flow and corresponding value setting to achieve the flow.
The ESP values that can be set may be different for each product and capacity.

Temperature sensor(2TH) setting (air conditioner / DX ventilator)

It is the function to select the temperature sensor to decide the indoor temperature.

- You can set the following setting values using [<,>(left/right)] button.




Temperature sensor location		Description
Remote controller		Operate the system with wired remote controller’s temperature sensor
Indoor Unit		Operate the system with indoor unit’s temperature sensor
2TH	Cool	Compare the temperatures of the indoor unit and the wired remote controller and operate with the higher temperature (There are system operated with lower temperature)
	Heat	Compare the temperatures of the indoor unit and the wired remote controller and operate with the lower temperature

- 2TH function’s operation characteristics may be different for each product.

Ceiling height setting (air conditioner)

It is the function to control the fan speed stage according to the ceiling height in the ceiling type product.

- You can set the following setting values using [<,>(left/right)] button.



Ceiling height	Description
Low	Fan speed operates one step slower than the default value.
Standard	Operates at the default fan speed
High	Fan speed operates one step faster than the default value.
Very high	Fan speed operates two steps faster than the default value.

!


NOTE

When group control is enabled some functions are limited depending on product type.

Static pressure setting(air conditioner)

Static pressure setting can be set only in the duct products. (It cannot be set in other products.)

- You can set the following setting values using [<,>(left/right)] button.




Static pressure		Description	
		Variable / Fixed	ESP default value
Variable high static pressure	V-H	Variable	High static pressure(High)
Fixed high static pressure	F-H	Fixed	High static pressure(High)
Variable low static pressure	V-L	Variable	Low static pressure(Low)
Fixed low static pressure	F-L	Fixed	Low static pressure(Low)

- 2TH function’s operation characteristics may be different for each product.

Remote controller master / slave setting
(air conditioner / General, DX ventilator)

This function sets configuration for the master/slave setting through the remote controller.

- Change setting values using [<,>(left/right)] button.




M/S	Description
Master (default)	Using group control, the indoor units are operated based on the remote controller.
Slave	Using group control, all remote controllers except 1 master remote controller are set as slaves.

- 2TH function’s operation characteristics may be different for each product.

Override Master/Slave setting (air conditioner / General, DX ventilator)

The operation master / slave selection function is to avoid other mode operations, and it is the function to prevent the selection of opposite mode of the indoor unit master by the indoor units set as slaves.

- Change setting values using [<,>(left/right)] button.




M/S	Description
Master	Using group control, this master sets the mode of slave IDU’s.
Slave	For the indoor unit set as slave, it can only select the some operation mode of the master indoor unit cycle. Ex) Master is in cooling cycle, Slave can select cooling, dehumidification, auto, and wind only Master is in heating cycle, Slave can select auto, heating, and wind only

! NOTE
Override M/S setting function is only available in some products.

Dry contact mode setting (air conditioner / general, DX ventilator)

Dry contact function is the function that can be used only when the dry contact devices is separately purchased and installed.

- Change setting values using [<,>(left/right)] button.



Value
Auto
manual


! NOTE

For dry contact mode related detail functions, refer to the individual dry contact manual.
What is dry contact?
It means the contact point signal input when the hotel card key, human body detection sensor, etc. are interfacing with the air conditioner.
Added system functionality by using external inputs (dry contacts and wet contacts).

Fixed air volume (air conditioner / DX ventilator)

It is the function to apply different fan speeds automatically for each thermal control status.

- You can set the following setting values using [<,>(left/right)] button.



Value	Comp on	Comp off
Variable	Set fan speed	Low
Fixed	Set fan speed	Set fan speed

Zone Type Setting (air conditioner)

This function is only available on some products.
This function select a type of zone control type which indoor unit support as 'new type' or 'old type'.

InstallerBackOK OK

SEER MODE✓

Fixed Air Volume< Variable >

Zone Type< New(8zone) >

Zone Number< 8 >

Over Heating< Step 0 >

Value
Old
New(4 Zone)
New(8 Zone)

Zone Number Setting (air conditioner)

This function is only available on some products.
Zone Number is to set the number of installed zones. It's possible to control only in zone new type.

InstallerBackOK OK

SEER MODE✓

Fixed Air Volume< Variable >

Zone Type< New(8zone) >

Zone Number< 8 >

Over Heating< Step 0 >

Value
New(4 zone) : 2~4
New(8 zone) : 2~8

Over Heating (air conditioner)

Provides an adjustable deadband around the heating setpoint through selectable heating thermal on/off values.

InstallerBackOK OK

SEER MODE✓

Fixed Air Volume< Variable >

Zone Type< Old >



Zone Number< 4 >

Over Heating< Step 0 >

Value
Step0 : Default value
Step1 : 4°C / 6°C
Step2 : 2°C / 4°C
Step3 : -1°C / 1°C
Step4 : -0.5°C / 0.5°C

Emergency heater setting (air conditioner)

- Enable the emergency heater control function and the usage environment.
- In the installer setting list, select the emergency heater setting category, and press [OK] button to move to the detail screen.
 - In case of an error, it sets whether the emergency heater can be used / outdoor temperature standard heater operation usage setting and temperature step value setting / and during the emergency heater operation, whether to use the indoor unit fan operation.




Value	Outdoor temperature standard heater operation		Fan operation in emergency control
Not use	-		-
Use	Emergency heater	Step 0 ~ 3	On/Off
	Extended emergency heater	Step 0 ~ 15	

! NOTE
This function setting must be carried out by a certified-technician.

Function control during group Control setting (air conditioner)

- This function enables the control of the common functions or some functions based on the master indoor unit during the group control.
- Change setting values using [<,>(left/right)] button.




Value	Description
TYPE0 (Not use)	Common function,
TYPE1 (Use)	Use expanded function which is based on master indoor unit

! NOTE
Common functions and some indoor unit master standard setting shall be set only during the group control with the same type indoor units.
During the group control with different indoor unit types, set it as '000' to use the existing group control method.

External devices of indoor unit setting (air conditioner)

At the Code field, select when air cleaner/heater/humidifier/elevation grill/ventilation KIT/Aux Heater/refrigerant leakage detection sensor are newly installed to the indoor unit or when an installed KIT is removed.


- You can set the following setting values using [<,>(left/right)] button.



Function	Value
Air purify	Not install / Install
Heater	
Humidifier	
Elevation grill	
Ventilation Kit	
Aux Heater	
Refrigerant leakage detection sensor	

Expand of Temperature Range (air conditioner)

This function using in dual setpoint control mode.
This function is used for select setting temperature range option.



Value
Clear : 60~86 °F / 16~30 °C (default)
Set : 40~99 °F / 4~37.5 °C

!

NOTE

When the set values are changed, the items below will be initialized.

- Target temperature (default: Cooling: 86 °F(30 °C)/ Heating: 60 °F(16 °C))
- 'home leave' temperature (default: Cooling: 86 °F(30 °C)/ Heating: 60 °F(16 °C))

In case of the setting expanded temperature range (set), please note that the setting of the wired remote controller can be altered under below circumstances.

- In case of cooling at 30~37.5 °C(64~99 °F), it is changed to cooling at 86 °F(30 °C).
- In case of heating at 4~15.5 °C(40~86 °F), it is changed to heating at 60 °F(16 °C).
- If set on dual setpoint, it is changed to the current operation mode(cooling or heating) of the indoor unit.


Situation where changes in the setting occur

- Operates the Auto address work and pipe search in situations such as product installment and service.
- Occurrence of errors and deactivation.
- Command generated by the central control, outdoor unit, Dry contact, Remote controller, indoor unit switch.

Indoor unit address verification (air conditioner / DX ventilator)

This function allows you to check the address of the indoor unit designated by the outdoor unit.


- In the installer setting list, select the indoor unit address check category, and press [OK] button to move to the detail screen.



Static pressure step setting (air conditioner)

It is the function to subdivide and set the product's Static pressure to 11 stages.

- Change setting values using [<,>(left/right)] button.



NOTE

If Static pressure step setting is used, the Static pressure setting is not used.
For the Static pressure step value for each stage, refer to the indoor unit product manual

Over Cooling (air conditioner)

Provides an adjustable deadband around the cooling setpoint through selectable cooling thermal on/off values.

Installer

Back

OK

OK

Elevation Unit

< Not Installed >

Ventilation Kit

< Installed >

Aux Heater

< Step 0 >

IDU Address Verification

>

Over Cooling

< Step 0 >

Value
Step0 : 0.5°C / -0.5°C
Step1 : 6°C / 4°C
Step2 : 4°C / 2°C
Step3 : 1°C / -1°C

Guard timer(air conditioner)

It is a function that sets the minimum running time of outdoor unit cycle mode when switching from cooling mode to heating mode and vice versa during Auto Operation mode.
Under the condition of cooling/heating switching, it switches between cooling and heating mode after operation during the time scheduled in the Guard timer.

Installer

Back

OK

OK

IDU Address Verification

>

Over Cooling

< Step 0 >

Static Pressure Step

< Step 0 >

Guard Timer

< Step 0 >

AC. Fan Oper. Interlocked With Vent.


< Off >

Step	Value
0	0 minute
1	15 minutes
2	30 minutes
3	45 minutes
4	60 minutes

Fan speed in Cooling thermal off (air conditioner)

Indoor unit fan, in cooling mode, during thermal off condition.

- Select value using [<,>(left/right)] button.




Value	
Low	Fan speed low
Off	Fan off
Setting	fan speed setting value

Primary heater setting(air conditioner)

It is the function to set the air conditioner fan operation if the ventilation is operated while the air conditioner operation is stopped when the air conditioner and the ventilation are installed to interface with each other.

- You can set the following setting values using [<,>(left/right)] button.




Value	Description
Not use	During the heating, heater is set to be used as secondary
Use	During the heating, heater is set to be used as main

Air conditioner Fan operation interlocked with ventilation setting (air conditioner)

It is the function to set the air conditioner fan operation if the ventilation is operated while the air conditioner operation is stopped when the air conditioner and the ventilation are installed to interface with each other.

- You can set the following setting values using [<,>(left/right)] button.




Value	Description
Off	The air conditioner indoor unit Fan is Off during the ventilation interface
On	The air conditioner indoor unit operates in very weak wind during the ventilation interface

- When the air conditioner operation is Off, if the ventilation product is in operation, the air conditioner fan shall be operated, and when the fan is in operation, dust may fall, so it is the function to set the air conditioner fan operation status in case of ventilation interface through the setting.

Indoor unit Auto-Start setting (air conditioner / DX ventilator)

It is a function that sets whether to restore the indoor unit operation by resuming the previous power-on state or as power-off state in the power failure compensation.

- You can set the following setting values using [<,>(left/right)] button.




Value	Description
Use	Use indoor unit auto restart
Not use	Not use indoor unit auto restart

Occupancy duration time setting(air conditioner)

It is a function that sets the light-on/occupancy duration after motion is detected when installing an occupancy sensor.

- You can set the following setting values using [<,>(left/right)] button.





Value
0 Minute
10 Minutes
30 Minutes
60 Minutes

CN_CC setting (air conditioner)

It is the function to set the usage of the indoor unit’s CN_CC port.

- Select CN_CC setting category, and press [OK] button to move to the detail screen.



Value	Description
DC auto install (default)	When power is applied to the product, indoor unit when the contact point is on in Dry Contact installed state recognizes Dry Contact installation
DC manual not install	Do not use (install) Dry Contact
DC manual install	Use (install) Dry Contact
Programmable DI/DO	Use as Programmable DI/DO (Simple On/Off)


 **NOTE**

CN_CC is the device connected to the indoor unit to recognize and control the external contact point.

CN_EXT setting (air conditioner / DX ventilator)

It is the function to set to control the external input and output according to DI/DO set by the customer using the indoor unit’s Dry Contact Port. (It is the function to decide the usage of the contact point port (CN_EXT) mounted in the indoor unit PCB.)

- In the installer setting list, select CN_EXT setting category, and press [OK] button to move to the detail screen.




Value	Description
Not use (default)	Use installer code No. 41 setting value (simple Dry Contact setting value)
Simple operation control	Simple operation On/Off
Single emergency stop	Indoor unit single emergency stop
Occupied / Unoccupied	Occupied / Unoccupied
All emergency stop	Indoor unit all emergency stop ※ It can be set only when there is indoor unit emergency stop function.
Window contact	Window contact ※ It can be set only when there is window contact function.
Window contact lock	Window contact with lock ※ It can be set only when there is window contact lock function.

Outdoor unit function master setting (air conditioner / DX ventilator)

It is the function to set the outdoor unit’s function Master / Slave.

- You can set the following setting values using [<,>(left/right)] button.



Value	Description
Slave	Cannot enter the Smart load control function setting Cannot enter the low noise operation time setting Cannot enter the refrigerant noise reduction setting Cannot enter the defrost mode setting
Master	Smart load control function setting is possible Low noise operation time setting is possible Refrigerant noise reduction setting is possible Low noise operation control main agent setting is possible Defrost mode setting is possible

 **CAUTION**

※ When you change the outdoor unit function master setting from master to slave, check the operation status of the outdoor unit function (outdoor unit low noise operation, smart load control) and make sure to stop the outdoor unit function before the change.

Fan continuous operation setting (air conditioner)

It is the function to set the indoor unit’s continued fan function usage. (It is the function to maximize the cooling/heating efficiency by the outdoor unit operating the indoor unit fan operation longer than the previous operation method.)

- You can set the following setting values using [<,>(left/right)] button.

Installer	Back OK OK
CN_EXT	Not Use >
ODU Function Master	< Slave >
Fan Continuous Operation	< Clear >
Low Noise Mode Priority	< ODU >
Display Room Temperature	< Not Use >

Value	Description
Clear	Do not use continued fan usage
Set	Use continued fan usage

Low Noise Mode Priority setting (air conditioner / DX ventilator)

It is the function to set the low noise mode control main agent. (It is the function to set that only one of the outdoor unit / remote controller can control the low noise operation.)


- You can set the following setting values using [<,>(left/right)] button.

Installer	Back OK OK
CN_EXT	Not Use >
ODU Function Master	< Slave >
Fan Continuous Operation	< Clear >
Low Noise Mode Priority	< ODU >
Display Room Temperature	< Not Use >


Value	Description
RMC	Ignore the outdoor unit PCB’s low noise operation Switch Setting value - Function setting – remote controller low noise operation time menu deactivation
ODU(default)	It is controlled in the outdoor unit itself according to the outdoor unit PCB’s low noise operation Switch Setting value - Function setting – remote controller low noise operation time menu deactivation

Human detection sensor (air conditioner)

- It is the function to set whether to install human detection sensor and operation standard value.
- In the installer setting list, after selecting human detection sensor setting category, if you press [OK] button, it moves to the detail screen.




- You can set the following setting values for each category using [<,> (left/right)] button.



Value	Description
Installation status	Not installed, basic installation, 90° rotation installation
Detection result sending cycle	5 s, 30 s, 1 min., 3 min.
Sensitivity setting	Standard, low sensitivity, high sensitivity
Temperature control option	Step 0 : Keeps the product running and uses the temperature power saving function. Step 1 : The operation of indoor units is stopped by using the temperature power saving function.
Detection Area Setting	Indoor floor area detection, 6X6, 12X6

Humidity sensing position (air conditioner)

- It is the function to set the location to detect humidity.
- You can use [<, > (left/right)] button to set the following setting values.




Value	Description
Remote controller (default value)	Humidity sensor of the remote controller itself
Indoor unit	Humidity received from indoor unit

ODU cycle priority (air conditioner)

This function can set cycle priority of outdoor unit.

Multi V Heat Pump system does not support mixed mode therefore wired remote controller can not show opposite operation mode for select option while ODU operate cooling or heating cycle.

Set this function user can select opposite operation mode with wired remote controller and indoor units enter to 'standby' status or outdoor unit can support cooling first and operate heating with heater.



Option	Description
Not use	Does not support opposite cycle operation using wired remote controller - When ODU operate as cooling cycle selectable operation modes with wired remote controller are cool, auto, dehumidification and fan. - When ODU operate as heating cycle selectable operation modes with wired remote controller are heat, auto and fan
Standby	When user set opposite operation mode using wired remote controller indoor unit stop thermal operation and fan.
Cool	Cooling cycle has a priority. When user change operation mode of specific indoor unit to cooling on heating cycle, outdoor unit change cycle to cooling and Indoor unit keep heating operation using heater. ✱ Please set emergency heater and aux heater function before using this option

✱ When user select cooling option, additional setting menu will be activated.


The additional timer setting menu is for setting minimum cooling operation period.

Once outdoor unit change over to cooling by cooling priority, outdoor unit can change over to heating after set time.

Setting value	Cooling operation time
Step 0	45 min.(default)
Step 1	30 min.
Step 2	60 min.
Step 3	90 min.
Step 4	120 min.

Outdoor temp. for heating stages (air conditioner)

It is a function that sets outdoor temperature values for two stage heating.
if user set outdoor temperature T1 and T2, Indoor unit will select heating stage between Indoor unit operation and heater operation.




SW Version	Setting value	Option	T1 value	T2 value
~2.08.2a	Not Use	-	-	-
	Use	-	-23 ~ 16 °C (-10 ~ 60 °F)	-23 ~ 51 °C (-10 ~ 130 °F)
2.09.0a~	Not Use	-	-	-
	Auto	-	-23 ~ 16 °C (-10 ~ 60 °F)	-23 ~ 51 °C (-10 ~ 130 °F)
		Heat pump	-	-
	Manual	Heater		
		Heater + H/P		

※ Even if the remote control version is 2.09.0a or more, Features may not be supported.

Estimated energy display (air conditioner)


This function can set to display energy data which outdoor unit estimated power consumption data without wattmeter.



Setting value	Description
Use	Display energy consumption data which outdoor unit estimated
Not Use	Not display energy consumption data which outdoor unit estimated

CN_PTC setting (air conditioner)

This is a function to set PTC Port of indoor unit.




Setting value	Description
Normal	Auxiliary heating interlock deactivated
Special	Auxiliary heating interlock activated

Server Room (air conditioner)





This is the function to set the “alternating and backup operation” to keep the temperature of the server room stable.

1. After selecting "Server Room" on the installer settings list, press the [OK] button to bring up a detailed view.




2. Set the “Usage Setting”, “Number of IDU”, “IDU Address”, the time and temperature settings for the alternate/backup operation.

Settings Menu	Setting Item	Setting Range	Description
Usage Setting	Select Usage Status	Enabled, Disabled	All sub-setting menus are activated when Enabled is selected.
	Number of IDU	2-4 (Unit)	-
IDU Address	A, B, C, D	00~FF	Enter the central control address of each indoor unit set after installation. ✳ Addresses to be entered are displayed as much as the setting value in the "Usage Setting" - "Number of IDU"
Interval	Hours	1~999	Set the cycle time for alternating operation. After the set time has elapsed, the next indoor unit group will start to operate.
Overlap	Minutes	1~59	Before alternating operation, you can set the time for all indoor units to operate to maintain the temperature. Example: When 4 indoor units are used in 24 hours of alternating operation cycle, and 10 mins of overlapping operation time is selected during alternation - A, B, C indoor units operate and D indoor unit stops for 23 hours and 50 mins - A, B, C, D operate for 10 mins
Temperature Difference	Degrees	1~6	When the difference between the indoor temperature and the desired temperature detected by each indoor unit is greater than or equal to the “Set Temperature Difference Value”, the standby unit is automatically operated and capacity backup operation is performed to reach the optimal temperature.



3. After completing installation, "Server Room Control" starts and the operation status is displayed on the screen.



• Example of screen when 4 indoor units are installed in ABC alternating operation

Operation mode	Operating status	Screen display
Alternating operation	A,B,C operating / D standby	
When an error occurs in C, error backup operation starts.	A,B,D operating / C standby	
"Capacity backup operation" or "Overlap"	All indoor unit operation	

What is Alternating Operation?
By preventing excessive operation of only certain products, product performance and the server room environment can be maintained stably.

Example :

- When installing 3 indoor units, AB → BC → AC → AB → ...(Cycle)
- When installing 4 indoor units, ABC → BCD → ACD → ABD → ABC → ...(Cycle)

What is Backup Operation?

- 1) Error backup operation: When an error occurs, error backup operation is performed to maintain the temperature by automatically operating the standby indoor unit. When all indoor unit errors are cleared, alternating operation is restarted.
- 2) Capacity backup operation: When the difference between the indoor temperature and the desired temperature detected by each indoor unit is greater than or equal to the "Set Temperature Difference Value", the standby unit is automatically operated and capacity backup operation is performed to reach the optimal temperature.

Example :


- Set Temperature Difference Value of 3°C, cooling operation mode engaged, desired temperature value of 25°C, indoor unit A detects a room temperature of 28°C or higher ⇒ Capacity backup operation performed.
- Set Temperature Difference Value of 3°C, cooling operation mode engaged, desired temperature value of 25°C, all indoor units detect indoor temperature of 25°C or less ⇒ Alternating operation restarts.

NOTE

- Server Room control works only in cooling and heating operation modes.
- Before using the "Server Room" function, it is necessary to set the central control address of the indoor unit and set group control.
- Please refer to the setting method with the wireless remote control in the product manual.


Password initialization (air conditioner / general, DX ventilator)

- It is the function to initialize (0000) when you forgot the password set in the remote controller.
- In the installer setting list, select the password initialization setting category, and press [OK] button to move to the detail screen.
 - When you press “initialization” button, a popup screen appears, and when you press “check” button, password initialization starts, and the user password is changed to 0000.



Auto ESP (air conditioner)


- This function automatically sets the rotation speed of the fans corresponding to each step of rated airflow for easy installation.
- Select Auto ESP and press the [OK] button to move to the detail screen.





After selecting the voltage setting, the product will automatically operate and automatically set the rotation speed for each fan speed - High, Medium, and Low.
Check the product type and select “Auto” for a Single product and “Manual” for a Multi V product.

Value	Description
Off	Not in use
Auto	Automatically selects the voltage
Manual	Selects the voltage (190V-270V) * Only for Multi V products

While setting, a pop-up is displayed. This means that Auto ESP is being set.
(It takes approximately 3 to 8 minutes.)



Product operation is terminated once the rotation speed setting is complete.
You can check the results as Pass or Fail.



If it fails, you cannot use the Auto ESP function.
Instead of Auto ESP, the conventional ESP setting method can be used.

! NOTE


If Auto ESP is incorrectly set, the air conditioner may malfunction.
This function must be set by an installation specialist with an installation license.

Noise Target Control

The Noise Target Control function is a function that limits the noise caused by the outdoor unit running.

Select the Noise Target Control item from the installer setting list and press the [OK] button to move to the lower settings screen.


- Set whether to use the Noise Target Control function and the noise limit.



Noise Target Control VER.1

Value	Noise limit (dB)				
Not use	-				
Use	50	55	60	65	70

- After setting, press the [OK] button to save the set value.
- If you press the [Back] button without pressing the [OK] button, the set value is not saved and it moves to the list screen.



Noise Target Control VER.2

- Set whether to use outdoor unit noise limitation, noise limitation value and start time for each time zone.
- Time must be set for at least 1 hour for each time zone. The same time cannot be selected across zones.

Use Setting	Daytime (dB) / evening (dB) / night (dB) noise limitation value (dB)				
Not use	-				
Use	50	55	60	65	70

Time Setting	Setting Value
Daytime	AM 1~12, PM 1~12
Evening	AM 1~12, PM 1~12
Nighttime	AM 1~12, PM 1~12

- After setting the use, press the [>] button to move to the time setting screen.
- Set the time and press the [V] button to save the set value.
- If you press the [Back] button without pressing the [OK] button, the set value will not be saved and the screen will move to the list screen.

!



NOTE

- The Noise Target Control function limits the product's capabilities to prioritize noise while running.
- Pay special attention to the settings as a weakening of cooling or heating may occur.
- The range of noise limits may vary depending on the version of the remote control and the connected product.
- The configuration of the screen displayed may vary depending on the remote control version and the connected product.

Dust step color setting

This function is to set the dust step color.

- In the install setting list, select the dust step color setting category and press [OK] to open the details window.





Value	Step
Type 1	4Step(for Korea)
Type 2	4Step(for Global)
Type 3	6Step(for China)

* The dust step color may not be displayed in some products.

UVnano / Filter Box

It is the function to set whether to mount option unit (UVnano/Filter box) when it is additionally installed or removed after the mass production

- You can set the following setting values using [<,>(left/right)] button.




Function	Value
UVnano	Not Installed / Installed
Filter Box	

Fan Operation During Auxiliary Heater Only

This is a function to set the indoor unit fan to be used even when the Auxiliary heater is operating alone.


- You can set the following setting values using [<,>(left/right)] button.



Value	
Not use	Use

Outdoor Temp Setting in Internal Heater

This function sets the outdoor temperature at which the internal heater is activated.
Select the “Outdoor Temp Setting in Internal Heater” item from the Installer Settings list and then press the [OK] button to move to the Sub-settings screen.




- Set whether to use the “Outdoor Temp Setting in Internal Heater” function and the outdoor temperature value.

Setting	Outdoor temperature
Not Use	-
Use	10~21 °C (50~70 °F)

Heater Enabled by Set Temp Differential

This function sets the Thermo On/Off temperature between the room temperature and the desired temperature when the heater is operating.
Select the “Heater Enabled by Set Temp Differential” item in the Installer Settings list and then press the [OK] button to move to the Sub-settings screen.



- Set whether to use the “Heater Enabled by Set Temp Differential” function and the heater operation temperature difference value.

Setting	Temp Difference to Enable Heater			
	Heater1 On	Heater1 Off	Heater2 On	Heater2 Off
Not Use	-			
Use	-5~5 °C (-10~10 °F)	-5~5 °C (-10~10 °F)	-5~5 °C (-10~10 °F)	-5~5 °C (-10~10 °F)

Minimum Temp Difference to Enable Heater

- “Heater1 Off” ≥ “Heater1 On” + 1°C (2°F)
- “Heater1 On” ≥ “Heater2 On” + 0.5°C (1°F)
- “Heater1 Off” ≥ “Heater2 Off” + 0.5°C (1°F)
- “Heater2 Off” ≥ “Heater2 On” + 1°C (2°F)
- ※ “Heater1 Off” > “Heater2 Off” > “Heater1 On” > “Heater2 On”


! NOTE

- “Heater Enabled by Set Temp Differential” may not be displayed/run in some products.
- Depending on the number of heaters installed in the indoor unit, some temperature difference values for heater operation may not be displayed.

Internal Heater During Defrost

This function keeps the internal heater in use during defrosting.

- You can use the [<, > (left/right)] buttons to set the following setting values.





Setting	Description
Not Use	Not use internal heater during defrost
Use	Use internal heater during defrost

Piping Address Setting

This feature sets the piping address of the "Multi" series.

- In the installer setting list, select the Piping Address setting category, and press [OK] button to move to the detail screen



Address code	
Branch Distribution Unit Address	Piping Address
-	-
0~3	A~E

- The left side of the setting value at the bottom of the address code is the distributor address, and the right side is the piping address setting value.



! NOTE

- Depending on the version of remote control, this feature may not be activated.
- This setting may differ from the value automatically set by the outdoor unit to the piping address.
- If the outdoor unit proceeds with automatic piping address setting, this setting will not be applied.

Refrigerant Leak Sensor Timer (air conditioner / DX ventilator)

This feature resets the life timer of the refrigerant leakage detection sensor.

- In the installer setting list, select Refrigerant Leak Sensor Timer category, and press [OK] button to move to the detail screen.



- Please make sure to reset the refrigerant leakage detection sensor, if you replaced it. The product may malfunction, if you don't reset it.

! NOTE

- Depending on the version of remote control, this feature may not be activated.

Power Line Fault Detection

This function is designed to protect the product when a fault is detected in the power supply.

- You can use the [<, > (left/right)] buttons to set the following setting values.

Installer	BackOKOK
Server Room	>
Noise Target Control	>
Power Line Fault Detection	< Not Use >
Password Initialization	>

Setting
Not Use
Use

! NOTE

- Depending on the version of the remote control, this function may not be activated.

Product direction (general ventilator)

It is the function to set the direction of the ventilation product.

- Select value using [<,>(left/right)] button.


Installer	BackOKOK
Product Direction	< Normal >
Express Ventilation Priority	< Air Exhaust >
RMC Master/Slave	< Master >
Override Master/Slave	< Slave >
Dry Contact Mode	< Auto >

Value	
Normal	Reverse

Express ventilation priority (general , DX ventilator)

It is the function to set the priority of the air supply and air discharge during the express ventilation operation.

- Select value using [<,>(left/right)] button.




Value	
Priority in air supply	Priority in air discharge

Humidification of stand-alone ventilation mode (DX ventilator)

It is the function to set whether to use the humidification function during the ventilation product single operation.

- Select value using [<,>(left/right)] button.




Value	
Not use	Use

Humidification of ventilation with heating operation (DX ventilator)

It is the function to set the heating humidification function of the direct ventilation to be automatic or manual.

- Select value using [<,>(left/right)] button.




Value	
Not use	Use

Ventilation Fan Speed Alignment (general ventilator)

It is the function to change the standard fan speed of the ventilation product.

- Select value using [<,>(left/right)] button.




Value			
Default value	10% increase	10% decrease	20% decrease

Filter check alarm(general ventilator)

This function sets the filter check alarm of the ventilation product.

- Select value using [<,>(left/right)] button.



Value
Step 0 - 5

GUIDE TO DIFFERENT MODE OPERATION/OPEN SOURCE SOFTWARE

Different mode operation

Different mode operation is the case when the indoor units' operation modes are different when multiple indoor units are installed to one outdoor unit. (Different mode operation doesn't happen in the cooling exclusive model.)

- Example of different mode operation
 - When one indoor unit is operated in heat while several indoor units one outdoor unit are operated in cooling, the heating operation is not performed.
 - With one outdoor unit, while several indoor units are in heat mode, if one indoor unit requests in cooling or dehumidification, the operation is not performed.

Open Source Software Notice Information

To obtain the source code that is contained in this product, under GPL, LGPL, MPL, and other open source licenses that have the obligation to disclose source code, and to access all referred license terms, copyright notices and other relevant documents, please visit <https://opensource.lge.com>.

LG Electronics will also provide open source code to you on CD-ROM for a charge covering the cost of performing such distribution (such as the cost of media, shipping, and handling) upon email request to opensource@lge.com.

This offer is valid to anyone in receipt of this information for a period of three years after our last shipment of this product.

